


The best way
to solve the matters
passes from
and our job is **producing**



mucit
Plastik Kalıp San. ve Tic. Ltd. Şti.

MERCEDES-BENZ 1-28

M.A.N. 29-32

VOLVO 33-35

SCANIA 36

DAF 37-38

TRAILER 38

UNIVERSAL PARTS 39

TRACTOR 40-46

RUBBER MOUNTING

| | | | |
|-------------|---|------------|-------------|
| MUCIT REF | MUP-BB-0001 | DIMENSIONS | 56X86/98X63 |
| OEM NO | 000 326 1781 | | |
| ENGINE TYPE | 2232/6X4-2232 S /6X4-2226/6X4-2226 S /6X4 | | |



RUBBER MOUNTING

| | | | |
|-------------|---|------------|-------------|
| MUCIT REF | MUP-BB-0002 | DIMENSIONS | 50X86/98X63 |
| OEM NO | 000 326 1581 | | |
| ENGINE TYPE | 1626L/LS-1632L/LS-1926 LS-2232L/6X2,LS/6X4-2226L/6X2,LS/6X4 | | |



RUBBER MOUNTING

| | | | |
|-------------|--------------|------------|-------------|
| MUCIT REF | MUP-BB-0003 | DIMENSIONS | 32X70/81X62 |
| OEM NO | 435 323 0085 | | |
| ENGINE TYPE | U1300 L | | |



RUBBER MOUNTING

| | | | |
|-------------|--|------------|-------------|
| MUCIT REF | MUP-BB-0004 | DIMENSIONS | 56X70/81X63 |
| OEM NO | 625 323 0085 | | |
| ENGINE TYPE | 3535AK-3538AK/K-3544 AK/K-3550AK-4850-4844-4853-5038AK | | |



RUBBER MOUNTING

| | | | |
|-------------|---|------------|-------------|
| MUCIT REF | MUP-BB-0005 | DIMENSIONS | 37X70/81X63 |
| OEM NO | 000 323 3785 | | |
| ENGINE TYPE | 1632/AK/AS/IS-1626/AK/AS/IS-1924LS-1926/A/AK/AS/S/K-1928LS-1932/A/AS/S/K 2026S/6X2/4-2032S/6X2/4-2219L/6X2-2226/6X2/4,S/6X4-2232/6X2/4,S/6X4 2626/A/B/AS/K/IS-2632/A/AS/S/K-2932AK-3332 | | |



RUBBER MOUNTING

| | | | |
|-------------|--|------------|-------------|
| MUCIT REF | MUP-BB-0006 | DIMENSIONS | 37X70/81X62 |
| OEM NO | 387 323 0285 | | |
| ENGINE TYPE | 1626/IS-1628/IS/L-1632/IS-1633/IS/L-1635/IS/SK-1636/IS/K-1638/IS-1644/IS-1650-1722/L-1726/K/L-1728-1729/K/IS-1733/L/LS-1735/K/IS/AF 1748/IS-1831/K-1834/K/IS-1838/IS/K-1844/K-1850/K/IS-1922/K/IS/AK/LK-1924LS-1926/K/IS-1927AK-1928/IS/K/AK-1929/A/AK/AS-1932/K/IS 1933/IS-1935/IS/AS/K/AK/LAS-1936/K/IS-1938/IS-1944/IS-1945/AK/A-1948/AK-2024/K/AK-2026S/6X2/4-2027AK-2028S-2031/A/K/AS-2032S/6X2/4 2033S-2035S/6X2/4-2038/AS/A/LAS-2044/AS/LAS-2050/AF-2055AF-2219C/CL 6X2/L 6X2-2220/L/6X22222/L 6X2-2225L 6X2-2226S/6X2/4 2228/IS/LS/FL/L/6X2-2232/IS/6X2/4-2233/IS/6X4-2235/IS/LS/K-2236/IS/L/LS-2238/IS/6X4-2420L-2422L-2427L-2428-2429/K/LS/IS/6X2/4-2433/L 2435/LS/L/IS/6X2/4-2438L-2444/L-2448/IS/LS-2524L-2527/L/IS/K/B-2529-2531/L/B-2534/L/K/IS/LS-2535/K/L/LS-2538/FL/IS/LS/K/LK-2544/L/IS/K/L/IS 2550/L/K/IS/LS-2553-2622-2626/B/K/IS-2628/B/S/K-2629/A/B/K/IS-2631/K/L/K/IS/L-2632/K/IS/6X4-2633/IS/LS-2634/IS-2635/LS/LS/L/K/A-2636/L/K/IS/LS 2638/L/K/LK/LS/IS-2644/LS/LS/L/K/LK-2648/IS/LS/K-2650A/L/K/IS/LS-2653/L/LS/LS-2828-2833-3228/B/K/L-3233/B/K-3234/B/K/L-3235/K-3238/L 3239/B/K-3244-3248-3250-3253-3328/B/K/8X4/4-3332-3333/B/K-3344-3335/K-3336/B/K/IS-3338-3528/B/K-3529-3534K-3535/B/K/L/AK 3536/K/IS-3538/K/AK-3544/K/IS-3548/K/IS-3550/IS/L-3553/IS/L-3636-3833-3835-4044S-4150K-4435/K-4436-4635-4644-4836-4844S-5053S-5248K | | |



RUBBER MOUNTING



| | | | |
|-------------|--|------------|-------------|
| MUCIT REF | MUP-BB-0007 | DIMENSIONS | 41X70/81X62 |
| OEM NO | 000 323 3985 | | |
| ENGINE TYPE | 1626AK/AS-1632AK/AS-1926A/AK/AS-1932A/AK/AS-2226L/6X2-2232L/6X2-2626A/AB/AS/6X6-2632A/AS/6X6 | | |

RUBBER MOUNTING



| | | | |
|-------------|---|------------|-------------|
| MUCIT REF | MUP-BB-0008 | DIMENSIONS | 41X70/81X62 |
| OEM NO | 387 323 0385 | | |
| ENGINE TYPE | 1222/FIS-1228/F-1245A-1414/K-1417 C/CS/CK-1419 C/CL-1420/L/LS-1422/F/L/LS/S/LL-1425/LS/S/L/F-1428 F-1429 F-1614/K/L-1617/C/CK/CL/CS-1619 C-1620/K/L/LL-1622/K/L/S/LL/LS-1625/L/LS/L/S/K-1626AK/AS-1628/L/LL-1632AK/AS-1733 L-1814-1919 C-1926A/AK/AS-1928A/AK/AS/K-1932A/AK/AS-1935A/AK-1936A/AK/AS/LAS-1945A/F/AF-2219 6X2/4/C/CL/6X2-2220/CL/6X2/L-2222/L/B/K/L/6X2-2225/L/B-2226L/6X2-2228A/L/LL-2232L/6X2-2233L/6X2-2235L-2236L/LS-2238/L-2244/L/LL-2422-2425/L-2428 L/A-2429L-2432 L-2433 L-2434L-2435L/LS-2436/A/AK/KA-2448L/LS-2528/A/AK-2532L-2535A/L-2536/A/AK/K-2538L-2544L-2550L-2626A/AB/AS/6X6-2628A/AS-2632A/AS-2636A/AS-2645AF-2822-2825-2828-3025/K/B-3028/B-3036/K/L-3228/B/K-3233/B-3235/L-3244L-3250L-3328/B/K/L-3335-3336/A/AK-3528/K-3535-3536AK-3820-3850A-4436AK-4445-4645-5436AK-6036AK | | |

RUBBER MOUNTING



| | | | |
|-------------|--|------------|-------------|
| MUCIT REF | MUP-BB-0009 | DIMENSIONS | 46X70/81X62 |
| OEM NO | 387 323 0185 | | |
| ENGINE TYPE | 1719-1919-1922/K/S/AK-1925AK-1928A/AK/AS-2025S/6X2/4-2219 C 6X2/4-2220-2222-2225-2422-2622 | | |

RUBBER MOUNTING



| | | | |
|-------------|-----------------------|------------|-------------|
| MUCIT REF | MUP-BB-0010 | DIMENSIONS | 46X70/81X62 |
| OEM NO | 000 323 3485 | | |
| ENGINE TYPE | 1719/AK/S-1919/K/AK/S | | |

RUBBER MOUNTING



| | | | |
|-------------|-----------------------------|------------|-------------|
| MUCIT REF | MUP-BB-0011 | DIMENSIONS | 51X70/81X62 |
| OEM NO | 617 323 0085 | | |
| ENGINE TYPE | 3025/K-3028-3228/K/B-3233/B | | |

RUBBER MOUNTING



| | | | |
|-------------|---|------------|-------------|
| MUCIT REF | MUP-BB-0012 | DIMENSIONS | 45X85/97X62 |
| OEM NO | 000 326 1681 | | |
| ENGINE TYPE | 1626/AK/AS/K/S-1632/AK/AS/K/S-1719/AK/K/S-1919/AK/K/S-1926/A/AK/AS/K/S-1932/A/AK/AS/K/S-2026S/6X2/4-2032S/6X2/4 | | |

RUBBER MOUNTING

MUCIT REF MUP-BB-0013
 OEM NO 387 326 0281
 ENGINE TYPE

DIMENSIONS 46X86/98X63

1222AF/FIS/LS-1225AF-1228F-1414K-1417CAK/CK-1422FIS-1425FIAFIS-1428F/AF-1429F/AF-1614K-1617CAK/CK/CS-1620K-1622AK/KIS/ALS-1625AK/KIS-1626IAK/ASIK/S-1628ULS-1632IAK/ASIK/S-1633ULS-1635ULS-1636IS-1638LS-1644ULS-1717K/IAK-1719IAK/KIS-1720S-1722K/IAK-1726 AK/KIS-1729ULS-1733ULS-1735ULS/IK-1748ULS-1820K/IAK-1824K/IAK/LAK-1827K/ISAK-1831L/AS/ULS-1834S/ULS-1838ULS-1844ULS-1850ULS/LAS/IK-1919IAK/KIS-1926IAK/ASIK/S-1928ULS-1929L-1932IAK/ASIK/S-1933LS-1935LS-1938LS-1944LS-2025S/6X2/4-2026S/6X2/4-2028LS-2032S/6X2/4-2033LS-2035LS-2036LS-2219C/6X2/4-2220 6X2,6X4-2222K-2225-2228L-2233L-2235L-2236ULS-2238L-2244ULS-2428L-2429ULS-2433S/IL-2434L-2435ULS-2444LS-2448ULS-2531L-2534L-2535L-2538ULS-2544ULS-2550ULS-2553LS-2650A/IS/L-3038L-3050S-3235L-3238L-3244L-3250L-3335A-3535L-3550L-3833-3835-3548S-3550S-3553S



RUBBER MOUNTING

MUCIT REF MUP-BB-0014
 OEM NO 387 326 0181
 ENGINE TYPE

DIMENSIONS 51X86/98X63

1626LS-1628L/LS-1632L/LS-1633L/LS-1636L/LS-1638LS-1733L-1926LS-1928L/LS-1932LS-1933LS-1936LS-1938LS-2028LS/6X2/4-2033LS/6X2/4-2036LS/6X2/4-2226/L 6X2-2226S/LS 6X4-2232/LS 6X4-2228L-2233L/6X2-2236L/LS-2238L-2428L-2433L-2544K-3025B/K8X4/4-3028K/B-3038L-3228K/L-3235K/IAK-3238L-3244-3250-3253-3328K-3528K/B-3535B/IK-3538K-3544K-3548K-3550K/IAK-4435K-4844K-4850-4853-5038AK



RUBBER MOUNTING

MUCIT REF MUP-BB-0015
 OEM NO 393 326 0481
 ENGINE TYPE

DIMENSIONS 56X86/98X63

2226 6X2,6X4-2226S 6X4-2232/S 6X2, 6X4-2228L/LF/LS/S-2233S/6X4-2235S/LS-2236S/LS-2238S/6X4-2244S/LS/6X4-2429S/LS-2435L/LS-2448S/LS-2535LS-2538K/L/LS-2544ULS-2550L/LS-2553S/LS-2635-2828-2833-3028B/K-3033B/K-3035-3228K/L-3235K-3238L-3244-3248-3250-3253-3255-3328K-3333K-3335K-3528B/K-3538K/IAK-3544K/S-3548K-3550K-4844K-4850-4853



RUBBER MOUNTING

MUCIT REF MUP-BB-0016
 OEM NO 621 323 0085
 ENGINE TYPE

DIMENSIONS 35X70/81X62

1245A-1424LAP-1729AK-1735AK-1831AK-1834AK-1835-1838-1844-1850-1853-1922AK-1925AK-1926AK,4X4-1927AK-1928IAK/ASIK-1929IA/ASIAK-1935IA/ASIAK/LAS-1936IA/ASIAK/LAS-1945IA/FIAK/AF-1948AK-2024AK/LAK-2027AK-2031A/AS/LAS-2038IA/AS/LAS-2044LA/LAS/AS-2050AF-2228A-2428A-2435-2528IAK-2529-2531L-2535IAK-2536IAK/IAK-2538-2544-2550-2553-2628IA/AS-2629IA/AS-2631A/AS-2635A/IAS-2636IAS-2638A/LA/IAS-2644A/AS-2645AS/AF-2648AS-2650A/AS-2653AS-3036-3235AK-3328B/K-3335IAK-3336-3528K-3535IAK/IAK-3536-3538K/IAK-3544S/KIAK-3548-3550L/IK/IAK-4050A/8X8-4436-4445-4635-4644-4645-4648-4844K-4850A/8X8-4853-5035-5038-5436-6030IAK



RUBBER MOUNTING

MUCIT REF MUP-BB-0017
 OEM NO 000 323 3885
 ENGINE TYPE

DIMENSIONS 33X70/82X62

2232 L/6X2-2226 L/6X2



RUBBER MOUNTING

MUCIT REF MUP-BB-0018
 OEM NO 000 326 0981
 ENGINE TYPE

DIMENSIONS Qi45 mm

LP/LPS 1418-LP/LPS 1424-LP/LPK/LPS 1624-LP/LPK/LPS 1626-LP/LPK/LPS 1632 LP 1636-LP/LPS 1924-LP/LPS 1926-LP/LPS 1932-LPS 2024/6X2-LPS 2032/6X2 LP/LPK/LPS 2224/6X4-LP/LPK/LPS 2226/6X4-LP/LPK/LPS 2232/6X2/6X4-LS 1624 L/LA/LS 1924



RUBBER MOUNTING



MUCIT REF MUP-BB-0019
OEM NO 000 323 3285
ENGINE TYPE

DIMENSIONS 36X70X69X92

RUBBER MOUNTING



MUCIT REF MUP-BB-0020
OEM NO 000 326 0881
ENGINE TYPE

DIMENSIONS 40X69X70X92

RUBBER MOUNTING



MUCIT REF MUP-BB-0021
OEM NO 393 326 0281
ENGINE TYPE 1017LS-1217L/LS-1419L/LS/CL-1420L/LS-1422L/LS/LL-1424L/LS-1425L/LS-1613L-1617L/CL-1619L-1620L/LL-1622L/LL-1624L/LS-1625L/LS/LL-1626L/LS-1628L/LL/LS-1632L/LS-1633L/LS-1635L/LS-1636L/LS-1638LS-1644LS-1729L/LS-1733L-1735L/LS/K-1748L/LS-1838L/LS-1844L/LS-1850K/L/LS/LAS-1935LS-1944LS-2028LS/6X2/4-2033LS/6X2/4-2035LS/6X2/4-2036LS/6X2/4-2219L 6X2,CL/6X2-2220L/6X2-2222L/6X2-2225L-2226 L/6X2-2228L/6X2-2232L/6X2-2233L/6X2-2235L-2236L-2238L-2244LS/L/LL-2425L-2428L-2433L-2429L/LS 6X2/4-2434L-2435L/LS 6X2/4-2438L-2448L/LS-2535L-2538L-2544L/LS-2550L-2553LS-2650L-3038L-3235L-3238L-3250L

DIMENSIONS 65X86X90

RUBBER MOUNTING



MUCIT REF MUP-BB-0022
OEM NO 393 326 0381
ENGINE TYPE 2226 LS/6X4-2232 LS/6X4

DIMENSIONS 60X86X90

RUBBER MOUNTING



MUCIT REF MUP-BB-0023
OEM NO 389 326 0081
ENGINE TYPE 1926LS-1928L/LS-1929L-1932LS-1933LS-1935LS-1936LS-1938LS-1944LS-2244LS-2444LS-2448L-2429L

DIMENSIONS 70X86X90

RUBBER MOUNTING



MUCIT REF MUP-BB-0024
OEM NO 383 326 0181
ENGINE TYPE 1013KO/S-1017AF/KO/S-1019AF/F-1213AKO/KO/S-1217AS/KO/S-1219AKO/KO/S-1413AK/K/AKO/KO-1419AK/K/AS/F/S-1424F/S-1613K/KO-1617K/AK/KO/S-1619K/AK/KO/S-1624K/S-2219 6X2-OF 1113/1313/1317/1617/1621

DIMENSIONS 50X81/95X100,5

STABILIZER BEARING

| | | | |
|-------------|--|------------|------------|
| MUCIT REF | MUP-BB-0033 | DIMENSIONS | 40X64X44,5 |
| OEM NO | 941 326 0350 | | |
| ENGINE TYPE | 1823-1828L-1831L-1835L-1839L-1840L-1843L-1848L-1853L-1857L-2016-2031-2040-2053-2523L-2528L-2531L-2535L-2540L-2543L-2548L-2553L-2557L-2628-2631L-2635L-2640L-2643L-2648L-2653L-2657L-3131L-3335-3340L-3343L-3348L-3353L-3357-4140-4143-4148 | | |



STABILIZER BEARING

| | | | |
|-------------|--|------------|-------------|
| MUCIT REF | MUP-BB-0034 | DIMENSIONS | 40X52/65X24 |
| OEM NO | 941 323 0350 | | |
| ENGINE TYPE | 1823-1828L-1831L-1835L-1839L-1840L-1843L-1848L-1853L-1857L-2016-2031-2040-2053-2523L-2528L-2531L-2535L-2540L-2543L-2548L-2553L-2557L-2628-2631L-2635L-2640L-2643L-2648L-2653L-2657L-3131L-3335-3340L-3343L-3348L-3353L-3357-4140-4143-4148 | | |



BUSHING

| | | | |
|-------------|---|------------|-------------|
| MUCIT REF | MUP-KB-0001 | DIMENSIONS | 25X35/45X25 |
| OEM NO | 620 323 0250 | | |
| ENGINE TYPE | 1245A-1350IKS-1424LAP-1635SISK-1636SJK-1638S-1722L-1726IKL-1728-1729AKIKS-1733LS-1735KISIAF-1735AK-1748S-1831IKIAK-1834KISIAK-1835-1838SJK-1844K-1853-1922IKSILKIAK-4X4-1927AK-1928SIAKIASIK-1929IAKIAS-1933S-1935SIAKIASILAS-1935AIAKIASILAS-1936AIAKIASILAS-1938S-1944S-1945AIFIAK-1948IAK-2024IKIAKIAK-2027AK-2028S-2031AIAKIASILAS-2033S-2035S-6X2/4-2038IASILAS-2044LILAS-2050IAF-2055AF-2119C-2220L-2222-2228IAIUIFILS-2233S-6X4-2235SISIK-2236SILS-2238S-6X4-2428IA-2429IKISIS-6X2/4-2433-2435SILSILK-6X2/4-2438-2444L-2448SILS-2524L-2527LUSIKIB-2528IAK-2529-2531LILB-2534LILKISILS-2535SILSILS-2536IAKIAK-2538SILSILKILK-2544LILSILKILK-2550LILSILSILK-2553-2622-2628IAIASIBSJK-2629IAIBIKIAS-2631AIAKIASILK-2635SILS-2634S-2635SILSILK-2635AIAK-2636LILKIASILS-2638LILKILSIAIILAS-2644AIAIASILSILK-2645ASIAF-2648IASILSILK-2650AIAIASILSILK-2653SILSILS-2828-2833-3028IBIK-3033BIK-3035-3036-3038-3053IA-3228IBIKL-3229IBIK-3233BIK-3234BIKIL-3235IKIAK-3238IBIKL-3244-3248-3250-3253-3328IBIK-3333BIK-3335AIAK-3336BIKIS-3338-3344-3528-3529-3538-3548-3350SIL-3353SIL-3528IBIK-3529-3534K-3535AIAIBIKIAK-3536IKIS-3538IKIAK-3544IKIBSIAK-3548KIS-3550IKLIAK-3636-3833-3835-4044S-4050AIAI-8X8-4150K-4435K-4436-4445-4536-4635-4644-4645-4648-4835-4844IKS-4850AIAI-8X8-5035-5038AK-5053S-5248K-6030IAK | | |



BUSHING

| | | | |
|-------------|---|------------|-------------|
| MUCIT REF | MUP-KB-0002 | DIMENSIONS | 25X35/45X28 |
| OEM NO | 000 323 0950 | | |
| ENGINE TYPE | 1626SIAKIAS-1632SIAKIAS-1719-1919-1926AIAKIASIAK-1932AIAKIASIAK-LS1924-LS1928-2026S/6X2/4-2032S/6X2/4-2219L/CL6X2, 6X2/4-2220L 6X2-2222L 6X2-2225L 6X2-2226S/6X2/4-2226L/6X2-2228L 6X2-2232S/6X2/4-2232L/6X2-2233L/6X2-2235L-2236L/LS-2238L-2244L/L-2420L-2422L-2427L-2428L-2429L-2433L-2434L-2435L/LS-2448L/LS-2524L-2527L-2531L-2532L-2534L-2535L-2538L-2544L-2550L/L-2626AIAIBIKIS/AB/IASI6X6-2632AIAIKIASI6X4/IASI6X6-3036L-3234L-3235L-3238L-3244L-3248-3250L-3332 | | |



BUSHING

| | | | |
|-------------|--|------------|-------------|
| MUCIT REF | MUP-KB-0003 | DIMENSIONS | 25X35/45X30 |
| OEM NO | 620 323 0050 | | |
| ENGINE TYPE | 1245A-1628SIL-1633SIL-1635S-1636L/LS-1638S-1733L-1922IKSIAK-1925AK-1928SIAKIASIAK-1933S-1935AIAK-1936AIAKIASIASILAS-1938S-1945AIFIAF-2025S/6X2/4-2028S-2033S-2220-2222-2225-2228AIAIUIFILS-2233S/6X4-2236SILS-2238S/6X4-2422-2428IA-2436AIAKIAK-2438L-2443-2528IAK-2535A-2536AIAKIK-2622-2628BISIKIAIAS-2633SILS-2636LILKISIAIAS/LS-2638S-2645AF-2828-2833-3028IBIK/8X4/4-3033BIK-3036IK-3038-3228IKIL-3235IK-3328IBIK/8X4/4-3333BIK-3336BIKIS-3338-3528IBIK-3535BIK-3536IKISIAK-3636-3820-3833-3850A-4436IAK-4445-4645-4836-5436AK-6036AK-3335-3336AIAK | | |



BUSHING

| | | | |
|-------------|--|------------|-------------|
| MUCIT REF | MUP-KB-0004 | DIMENSIONS | 32X44/50X35 |
| OEM NO | 000 326 0250 | | |
| ENGINE TYPE | 1626AIAKIASIKISILS-1632AIAKIASIKISILS-1719AIAKIAS-1919AIAKIAS-2026S/ 6X2/4-2032S/ 6X2/4-2226SILS/LS 6X2/LS 6X4, 6X2/4, S 6X4-2232/LS 6X4, S 6X2/4-LP/LPS 1418-LP/LPS 1424-LP/LPK/LPS 1624-LP/LPK/LPS 1626-LP/LPK/LPS 1632-LP 1636-LP/LPS 1924-LP/LPS 1926-LP/LPS 1932-LPS 2024/6X2-LPS 2032/6X2-LP/LPK/LPS 2224/6X4-LP/LPK/LPS 2226/6X4-LP/LPK/LPS 2232/6X2/6X4-LS 1624-L/LA/LS 1924 | | |



BUSHING



| | | | |
|-------------|---|------------|-------------|
| MUCIT REF | MUP-KB-0005 | DIMENSIONS | 32X44/52X37 |
| OEM NO | 387 326 0050 | | |
| ENGINE TYPE | 1628/LS-1633/LS-1636/LS-1638LS-1733L-1928/LS-1933LS-1936LS-1938LS-2028LS/ 6X2/4-2033LS/ 6X2/4-2036LS/ 6X2/4-2228/L/FF/LS/LS-2233L/ 6X2/5 6X4-2235/LS/LS-2236L/LS/LS-2238LS/ 6X4-2244/LS/LS/ 6X4-2428L-2429/LS/LS-2433L-2435/L/LS/LS-2448/LS/LS-2535LS-2538/K/LS/LS-2544/L/LS-2550/L/LS/LS-2553S/LS-2622-2635-2650A-2828-2833-3025B/K 8X4/4-3028/B/K-3033B/K-3035-3228/K/L-3235/K-3238-3244-3248-3250-3253-3255-3328/K-3333K-3335/K/A-3528/K/B/L-3535/K/B/L-3538/K-3544/K-3548/K-3550L-3833-3835-4435K | | |

BUSHING



| | | | |
|-------------|--|------------|-------------|
| MUCIT REF | MUP-KB-0006 | DIMENSIONS | 32X44/54X25 |
| OEM NO | 000 323 2150 | | |
| ENGINE TYPE | 1245A-1350/K/S-1424LAP-1626/S/AK/AS-1628/S/L-1632/S/AK/AS-1633/S/L-1635/S/SK-1636/L/S/K-1638/S-1644/L/S-1650-1719-1722/L-1726/K/L-1728-1729/K/S/AK-1733/L/LS-1735/K/S/AK/AS-1748/S-1831/K/AK-1834/K/S/AK-1835-1838/S/K-1844/K-1850-1853-1919-1922/K/S/AK/LK-1924-1925AK-1926/A/K/S/AK/AS-1926AK,4X4-1927AK-1928/A/S/K/AK/AS-1929/A/AK/AS-1932/A/K/S/AK/AS/LS-1933/S-1935/A/S/K/AK/AS-1936/A/K/S/AK/AS/LAS-1938/S-1944/S-1945/A/FF/AK/AS-1948/AK-2024/K/AK/LAK-2025/S/6X2/4-2026/S/6X2/4-2027AK-2028S-2031/A/K/S/AS/LAS-2032S/6X2/4-2033S-2035S/6X2/4-2038/A/S/A/LAS-2044/A/AS/LAS-2050/A/AF-2055AF-2219 6X2/4, C/CL 6X2/L 6X2-2220/L/6X2-2222/L 6X2-2225/L 6X2-2226/S/6X2/4, L/6X2-2228/A/S/L/S/FF/L/6X2-2232/S/6X2/4, L/6X2-2233/S/6X4, L/6X2-2235/L/S/L/K-2236/S/L/LS-2238/L/S/6X4-2244/L/L-2420L-2422/L-2427L-2428/A/L-2429/L/K/LS/S/6X2/4-2433/L-2434L-2435/L/S/L/S/6X2/4-2436/A/AK/KA-2443-2438L-2444/L-2448/L/S/LS-2524L-2527/L/S/K/B-2528/A/AK-2529-2531/L/B-2532L-2534/L/K/S/LS-2535/A/K/L/LS-2536/A/AK/K-2538/F/L/S/L/K/LK-2544/L/S/K/LK/LS-2550/L/K/S/LS-2553-2622-2626/A/B/K/S/AS/AB/6X6-2628/A/B/S/K/AS-2629/A/B/K/S/AS-2631/L/L/K/S/LK/A/AS-2632/A/AS/K/S/6X4-2633/S/LS-2634/S-2635/AS/LS/L/K/A-2636/A/AS/L/K/S/LS-2638/LA/LA/LAS/K/LK/LS/LS-2644/A/AS/LS/L/K/LK-2645AS/AF-2648/S/AS/LS/K-2650A/L/K/S/LS/AS-2653/L/S/LS/AS-2828-2833-3028/B/K/8X4/4-3033/B/K-3035-3036/K/L-3038-3050-3053/A-3228/B/K/L-3233/B/K-3234/B/K/L-3235/K/L/AK-3238/L-3239/B/K-3244/L-3248-3250/L-3253-3328/K/B/K/8X4/4-3332LS-3333/B/K-3335/A/K/AK-3336/A/B/K/S/AK-3338-3344-3528/B/K-3529-3535/A/B/K/L/AK-3536/K/S/AK-3538/K/AK-3544/K/S/AK-3548/K/S-3550/L/K/AK-3553/S/L-3636-3820-3833-3835-3850A-4044S-4050A/8X8-4150K-4435/K-4436/AK-4445-4635-4644-4645-4648-4836-4844/S/K-4850/A/8X8-4853-5035-5038-5053S-5248K-5436/AK-6030/AK-6036AK- | | |

BUSHING



| | | | |
|-------------|--|------------|---------------|
| MUCIT REF | MUP-KB-0007 | DIMENSIONS | 35X55/65X19,5 |
| OEM NO | 617 326 0050 | | |
| ENGINE TYPE | 1222AF/F/S/LS-1225AF-1228F-1414K-1417CAK/CK-1422F/S-1425F/AF/S-1428/AF-1429F/AF-1614K-1617CAK/CK/CS-1620K-1622AK/K/S/A/LS-1625AK/K/S-1717K/AK-1720S-1722/K/AK-1726AK/K/S-1733L/LA-1820K/AK-1824K/AK/LAK-1827/K/S/AK-1831/LAS-1834S-1834S-2025S/ 6X2/4-2219C/ 6X2/4-2220 6X2/4-2222K-2225-2228-2433/S | | |

BUSHING



| | | | |
|-------------|--|------------|-------------|
| MUCIT REF | MUP-KB-0008 | DIMENSIONS | 40X52/62X25 |
| OEM NO | 000 326 0650 | | |
| ENGINE TYPE | 1222AF/F/S/LS-1225AF-1228F-1414K-1417CAK/CK-1422F/S-1425F/AF/S-1428F/AF-1429F/AF-1614K-1617CAK/CK/CS-1620K-1622AK/K/S/A/LS-1625AK/K/S-1626LS-1628L/LS-1632L/LS-1633L/LS-1636L/LS-1638LS-1717K/AK-1720S-1722/K/AK-1726AK/K/S-1733L/LS-1820K/AK-1824K/AK/LAK-1827/K/S/AK-1831/LAS-1834S-1926LS-1928L/LS-1933LS-1936LS-1938LS-2025S/ 6X2/4-2028LS/ 6X2/4-2033LS/ 6X2/4-2219C/ 6X2/4-2220 6X2/4- 2222K-2225-2226/L/S/LS 6X4-2228/L/FF/LS/LS-2232/L 6X4/S 6X2/4-2233/S/ 6X4 /L/ 6X2-2235/LS/LS-2236/L/S/LS-2238/ 6X4/L-2244/S/LS/ 6X4-2428L-2429/LS/LS-2433/S/L-2435/L/LS/LS-2448/LS/LS-2535LS-2544/S/L-2550/L/LS/LS-2553/LS-2622-2635-2650A-2828-2833-3025B/K 8X4/4-3028/B/K-3033B/K-3035-3228/K/L-3235/K-3333K-3335/K/A/L-3238-3244-3248-3253-3255-3328/B/K-3528/K/B-3535/B/K-3538/K-3544/K-3548K-3550/L-3833-3835-4435K-4844/K-4850-4853 | | |

BUSHING



| | | | |
|-------------|--|------------|-------------|
| MUCIT REF | MUP-KB-0009 | DIMENSIONS | 44X56/66X25 |
| OEM NO | 620 323 0350 | | |
| ENGINE TYPE | 1628/LS-1633L/LS-1635L/LS-1636LS-1638LS-1644L/LS-1729/LS-1735L/LS/K-1748L/LS-1831L/LS-1834L/LS-1838L/LS-1844L/LS-1850L/LS/LAS/K-1928L/LS-1929L-1933LS-1938LS-1944LS-2028LS-2033LS-2035LS-2036LS-2228L-2233L-2236L/LS-2238L-2244L-1429L/LS-2433L-2434L-2435L/LS-2448L/LS-2531L-2534L-2535L-2538L/LS-2544K/L/LS-2550L/LS-2553LS-2650S/L-3028/K-3038L-3050S/LS-3228/K/L-3235/K/AK-3235L-3238/L-3244/L-3250/L-3328/K/B-3253-3535/K/B-3544/K-3548/S/K-3550/K/AK/S-3553S-4435K-4844/K-4850-4853-5038AK | | |

BUSHING

| | | | |
|-------------|--|------------|-----------------|
| MUCIT REF | MUP-KB-0010 | DIMENSIONS | 58,5X70/80X19,5 |
| OEM NO | 620 323 0150 | | |
| ENGINE TYPE | 1245A-1424AP-1628L/LS-1633L/LS-1635L/LS-1636LS-1638LS-1644L/LS-1729L/LS/AK-1735L/LS/K/AK-1748L/LS-1831L/LS/AK-1834L/LS/AK-1835-1838L/LS-1844L/LS-1850L/LS/LAS/K-1853-1922AK-1925AK-1926AK, 4x4-1927AK-1928A/K/L/LS/AK/AS-1929A/L/AS/AK-1933LS-1935A/L/AS/AK/LS/LAS-1936A/L/AS/AK/LAS-1938LS-1944LS-1945A/AF/AK/AF-1948AK-2024AK/LAK-2027AK-2028LS-2031A/AS/LAS-2033LS-2035LS/6X2/4-2036LS-2038A/L/AS/LAS-2044L/LAS/AS-2050AF-2228L/A-2233L-2235L-2236L/LS-2238L-2244L/LS-2428A/L-2429L/LS/6X2/4-2433L-2434L-2435L/LS/6X2/4-2444LS-2448L/LS-2528A/AK-2529-2531L-2534L-2535A/K/L-2536A/K/AK-2538L/LS/LS-2544L/LS-2550L/LS-2553LS-2628A/AS-2629A/AS-2631A/AS2635A/L/AS-2636/AS-2638A/L/AS-2644A/AS-2645A/AF-2648AS-2650A/LS/LAS-2653AS-3028B/K-3036-3038L-3050LS-3053A-3228B/K/L-3235K/L/AK-3238L-3244L-3250L-3253-3328K/B/K-3335A/AK-3336-3528B/K-3534K-3535A/L/K/B/AK-3536-3538K/AK-3544K/LS/AK-3548K/LS-3550S/LS/K/L/AK-3553S-4050A/8X8-4435K-4436-4445-4644-4645-4648-4844K-4850A/8X8-4853-5035-5038-5436-6030/AK | | |



CABIN BUSHING

| | | | |
|-------------|--|------------|-------------|
| MUCIT REF | MUP-KB-0011 | DIMENSIONS | 25X34/50X43 |
| OEM NO | 363 891 0617 | | |
| ENGINE TYPE | 1619/L-1622L/LL-1624/L-1625L/LL-1628L/LL/S/LS-1633/S/LS-1636/LS-1638/S/LS-1928/S/L/LS-1933/LS/S-1936-1938/S/LS-2028LS-2033S/LS-2225L-2228/S/L-2233/S/L-2236/L-2238L/LS-2425L-2428L-2423-2438L-2633/S/LS-2638/S-2833-3033/B/K-3038L-3333B/K-3338-3833 | | |



BUSHING

| | | | |
|-------------|--|------------|-------------|
| MUCIT REF | MUP-KB-0012 | DIMENSIONS | 18X26/35X15 |
| OEM NO | 314 326 0481 | | |
| ENGINE TYPE | L 406DG/407D/408G/409L/410/508DG/608D- LK 406DG/407D/408G/409/410/508DG/608D- LF 408G/409/410-LP 808/809/811/813/913-LKO 406DG/407D/408G/409/508DG-LPO 808/809/811/813/608/709-LPS608/709/811/813/913- LPK 808/809/811/813/913- LPKF 608/709/808/809-LPKO 608/709- O 309 D/B | | |



CABIN RUBBER BUSHING

| | | | |
|-------------|--|------------|----------|
| MUCIT REF | MUP-KKB-0001 | DIMENSIONS | 59X20X12 |
| OEM NO | 387 891 1910 | | |
| ENGINE TYPE | 1619/L-1622L/LL-1624/L-1625L/LL-1628L/LL/S/LS-1633/S/LS-1636/LS-1638/S/LS-1928/S/L/LS-1933/LS/S-1936-1938/S/LS-2028LS-2033S/LS-2225L-2228/S/L-2233/S/L-2236/L-2238L/LS-2425L-2428L-2423-2438L-2633/S/LS-2638/S-2833-3033/B/K-3038L-3333B/K-3338-3833 | | |



CABIN RUBBER BUSHING

| | | | |
|-------------|--|------------|----------|
| MUCIT REF | MUP-KKB-0002 | DIMENSIONS | 18X46X27 |
| OEM NO | 387 891 0272 | | |
| ENGINE TYPE | 1619/L-1622L/LL-1624/L-1625L/LL-1628L/LL/S/LS-1633/S/LS-1636/LS-1638/S/LS-1928/S/L/LS-1933/LS/S-1936-1938/S/LS-2028LS-2033S/LS-2225L-2228/S/L-2233/S/L-2236/L-2238L/LS-2425L-2428L-2423-2438L-2633/S/LS-2638/S-2833-3033/B/K-3038L-3333B/K-3338-3833 | | |



RUBBER MOUNTING

| | | | |
|-------------|---|------------|----------|
| MUCIT REF | MUP-KCB-0016 | DIMENSIONS | 20X40X39 |
| OEM NO | 000 323 2885 | | |
| ENGINE TYPE | 609D-709D-711D-809D-811D/DK-814/K/S/F/KO/L/D/DA-817L/LS-914/AK/K/KO-0 817L-0 1117/L-1117S/K/LS-1317/S-1517-1823/L-1833/L-1922/AK/K/LK/S-2024/LAK/AK/K-2528L-2533L-2538K/LK/LS/LS/F/L-2544S/LS/K/L-2628-2633 | | |



BOOT



| | | | |
|--------------------|---|-------------------|-----------------|
| MUCIT REF | MUP-KKB-0004 | DIMENSIONS | 20X58X21 |
| OEM NO | 620 268 0196 | | |
| ENGINE TYPE | 709K-809/K-0 814/L/F/K/KO/LS-0 817/L/F/K/L/LS/S-914/AK/K/KO-917AF-1013/A/AK/K/KO/S-1017/A/AK/AS/F/K/KO/LS/S-1019AF/F-1114/AK/K/L/S-0 1114/L42/L49-1117/A/K/L/LS/S-0 1117/L-1120/A/F/F/L/LS/S-0 1120/L-1213/A/AK/AKO/AS/K/KO/S-1217/A/AK/AS/K/KO/L/LS/S-1219/A/AK/AS/K/KO/S-1222/A/AK/AS/F/L/S-1225AF-1228F-1314/AK/K/KO/L-1317/AK/K/L/LS/S-1320/L/LS/S-1413/A/AK/AKO/K/KO-1414/K-1417/A/AK/AKO/K/KO/C/CAK/CK/CS-1419/AK/AS/F/K/L/LS/S/C/CL/-1420/L/LS-1422/F/L/LS/S-1424/F/K/LS/S-1425AF/F/L/LS/S-1428AF/F-1514L-1517/K/L-1520/L-1613/K/KO/L-1614/K/L-1617/AK/K/KO/L/S/C/CAK/CK/CL/CS-1619/A/AK/K/KO/L/S/C-1620/K/L-1622/AK/K/L/LS/S-1624/K/L/LS-1625/AK/K/L/LAK/L/LS/S-1626/A/S/K/L/LS/S-1628/L/LS/S-1632-1633/L/LS/S-1635K-1636/L/LS/S-1638/L/LS/S-1719/AK/K/S-1722/L-1726/K/L/LS/S-1729/AK/K-1733/L/S-1735/K/AF-1814-1919/AK/K/S-1922/AK/K/S-1925AK-1926/A/AK/AS/K/S/LS-1928/A/AK/K/L/LS/S-1929/A/AK/AS/K-1932/A/AK/AS/K/S/LS-1933/L/S-1935/A/AK/AS/K-1936/A/AS/LAS/L/S/K/S-1938/L/S-1945A-2025/S-2026S 6X2/I4-2028/S 6X2/I4-2032S 6X2/I4-2033/S 6X2/I4-2036/S 6X2/I4-2219 6X2/I4, 6X2/L, 6X2-2020/L-2222/K/L/B-2224 6X2/6X4, B 6X4, K 6X4, S 6X4-2225/L/B-2226 6X2/L 6X2, 6X4/ LS 6X4, S 6X4, 2228/A/L/LS/S-2232 6X2/L 6X2/6X4/S 6X4-2233/S 6X2/S 6X4-2235K-2236/S 6X4-2238/S 6X4-2422-2425/L-2428/L/A-2433-2435-2436-2438/L-2528/A/AK-2529-2535A-2536/A/AK/K-2622-2626 6X4/B 6X4/K 6X4/S 6X4/A 6X6/AB 6X6/AK 6X6/AS 6X6-2628/A/AK/AS/B/K/S-2629/A/AK/AS/B/K-2632 6X4/K 6X4/S 6X4/AK 6X6/AS 6X6-2633/L/S-2635/A/AK/AS/K-2636/A/AK/AS/L/LS/S-2638/S-2822-2825-2828-2833-3025/B/K-3028/B/K-3033-3036/K-3038/L-3228-3229/B/K-3235-3236A 6X6-3250A 6X6-3328/B/K-3332-3333/B/K-3335/A-3336A/AK/B/K/S-3338-3528-3535/AK/B/K-3536/AK/S-3636-3833-3850A 6X6-4435K-4436/AK-4445-4645 | | |

RUBBER MOUNTING



| | | | |
|--------------------|--|-------------------|-------------------|
| MUCIT REF | MUP-KCB-0017 | DIMENSIONS | 18X32,5X31 |
| OEM NO | 000 323 7885 | | |
| ENGINE TYPE | 214-208CDI-211CDI-213CDI-216CDI-308CDI-311CDI-313CDI-316CDI-314 SPRINTER 208D/210D/212D/308D/310D/312D/314 | | |

RUBBER MOUNTING



| | | | |
|--------------------|--|-------------------|----------------|
| MUCIT REF | MUP-KCB-0018 | DIMENSIONS | 9X26X24 |
| OEM NO | 901 323 0285 | | |
| ENGINE TYPE | 214-208CDI-211CDI-213CDI-216CDI-308CDI-311CDI-313CDI-316CDI-314 SPRINTER 208D/210D/212D/308D/310D/312D/314 | | |

RUBBER MOUNTING



| | | | |
|--------------------|--|-------------------|-------------------|
| MUCIT REF | MUP-KCB-0040 | DIMENSIONS | 25,5X75X65 |
| OEM NO | 381 317 1512 | | |
| ENGINE TYPE | 917/S/K/AK-1013/S/A/AK/K/KO-1017/K/S/F/A/L/S/KO/AK/AS/AF-1019AF/F-1213/K/S/A/AK/AK/AS/AKO-1214A-1217CA/L/S/L/K/S/KO/A/AK/AS-1219/K/S/F/A/AK/AF-1222/F/S/L/S/A/LA/AF/AS/L-1224F/AF-1226AF-1227AF/LAS-1231AF-1234AF-1413/A/K/KO/AKO/AK-1414/K-1419C/L/L/L/S/K/S/F/AK/AS-1420/L/LS/AK-1422/L/LS/L/S/F-1417/A/K/AK/CAK/CAK/C/CAK/AKO-1424/L/LS/AK/F/K/S-1425/L/S/S/F/AF-1426/L/S/S/F-1427/L/S/S/F-1428F/AF-1429AF/F-1431F-1442AF-1518/K-1521/S/K/AK-1613/L/K/KO-1614/L/K-1617/C/CK/CS/CL/K/S/L/CAK/KO/AK-1619/C/L/K/S/KO/A/AK-1620/K/L/L-1622/L/L/AK/AS/L/S/K-1624/L/S/K/S-1625/L/S/L/L/AK/K/S/LAK-1626/L/S/S/K/AS/AK-1627/A/AF-1628A/L/L/LS/S-1632/L/S/AK/AS/K/S-1633/L/S-1635/L/S/S/K-1636K/S/L/S/L-1717/K/AK/L-1719/S/K/AK-1720/S/L-1722/L/L/K-1724AK-1726/L/L/LS-1727L-1728-1729/S/L/K/S/AK-1732L-1733/L/S-1735/L/S/L/AK/S-1814-1820/K/AK/L-1824/L/K/AK/LAK-1827/L/LS/S/AK/K-1831/L/LS/K/AK/LAS-1834/L/S/AK/K-1838/L/S/K/S-1844/L/S/K-1850/S/K-1853-1919/S/AK/K-1922/K/S/L/K/AK-1926/AK/AS/AS/AK/S/ 4X4, 4X2-1927AK-1928/S/A/AK/L/S/K-1929/AK/AS/K/S/A-1932/S/AS/AK/AS/K-1935/S/K/AK/AS/LAS/A-1936/S/K/AS/LAS-1945/A/AF/F-1948AK-2024/K/AK/LAK-2025S-2026S/ 6X2-2027AK-2028A/ 6X6/L/S 6X2/S-2029/A/ 6X6-2031/A/K/S/AS/LAS-2032S/ 6X2-2035/S/ 6X2/S-2036/S/ 6X4-2044/LA-2050AF-2219C/CL/ 6X2/KO/K/ 6X4-2220/L-2222/L/K/B-2224/S/B/K/ 6X4/ 6X2-2225/L-2226/L 6X2/L/S/ 6X4-2228/L/L/S/L/S/F-2232/L 6X2/L/S 6X4-2235/L/K/S/LS-2236/L/S/LS-2320L-2420/L-2421-2422/L/K-2425-2426/L/B-2427/L/B-2428-2429/S/K/L/LS/ 6X2-2431-2432L-2433/L/S/L/K-2434L2435/L/S/S-2448/L/S-2517/K/ 6X2-2524/L/K-2527/B/K/L-2529-2531/L/B-2534/S/L/S/L/K/L-2535/K-2538F/L/S/L/K/LK-2544/K/L/S/LK-2550/L/K-2553/K-2626/AB/AK/AS/B/K/S-2628/K/S/AK/AS/B-2629/B/S/K/AS/K/ 6X6-2631/L/A/AS/AK/K/LK-2632/K/AS/AK-2635/L/S/L/S/AK/AS/AK-2636/A/AK/AS/K/S/LS-2638/K/AK-2644K-2645AS/AF-2648AS/S-2650S/AK/A-2653AK-3025/K/B-3028/K-3035-3036-3228/K/L-3231L-3233/B-3234L-3235/L/K-3238/L-3244-3228/K/B-3332-3335/AK-3336/B/K-3528/K/B-3529-3535/K/L/A/B/AK-3536-3538-3548-3550L-3835-3836AK-4436-4445-4635-4644-4645-4648-4836-4850-5035-5436-6036/AK | | |

RUBBER MOUNTING

| | | | |
|-------------|--|------------|---------------|
| MUCIT REF | MUP-KCB-0041 | DIMENSIONS | 46X50X88/17,5 |
| OEM NO | 381 317 1412 | | |
| ENGINE TYPE | 917/S/K/AK-1013/S/A/AK/KO-1017/K/S/F/A/S/KO/AK/AS/AF-1019A/F-1213/K/S/A/KO/AK/AS/AKO-1214A-1217CA/LS/L/K/S/KO/A/AK/AS-1219/K/S/F/A/AK/AF-1222/F/S/L/A/LA/AF/AS/L-1224F/AF-1226AF-1227AF/LAS-1231AF-1234AF-1413/A/K/KO/AK/AK-1414/K-1419C/L/L/L/S/K/S/F/AK/AS-1420/L/S/AK-1422/L/L/S/L/S/F-1417/A/K/AK/CA/K/CA/C/K/C/KO/AKO-1424/L/S/AK/F/K/S-1425/L/S/S/F/AF-1426/L/S/F/S-1427/S/AF-1428F/AF-1429A/F-1431F-1442AF-1518/K-1521/S/K/AK-1613/L/K/KO-1614/L/K-1617/C/C/K/S/L/K/S/L/CA/K/KO/AK-1619/C/L/K/S/KO/AK-1620/K/L/L-1622/L/L/A/AK/S/L/S/K-1624/L/S/K/S-1625/L/S/L/AK/K/S/LAK-1626/L/S/S/K/AS/AK-1627A/AF-1628A/L/L/L/S-1632/L/S/AK/AS/K/S-1633/L/S-1635/L/S/S/K-1636K/S/L/S/L-1717/K/AK/L-1719/S/K/AK-1720/S/L-1722/L/L/LK-1724AK-1726/L/L/L/S-1727L-1728-1729/L/S/L/K/S/AK-1732L-1733/L/S-1735/L/S/L/AK/S-1814-1820/K/AK/L-1824/L/K/AK/LAK-1827/L/S/S/AK/K-1831/L/S/K/AK/LAS-1834/L/S/AK/K-1838/L/S/L/S-1844/L/S/K-1850/S/K-1853-1919/S/AK/K-1922/K/S/L/K/AK-1926/AK/S/AS/A/K/S 4X4, 4X2-1927AK-1928/S/A/AK/L/S/LK-1929/AK/AS/K/S/A-1932/L/S/AS | | |



RUBBER MOUNTING

| | | | |
|-------------|---|------------|------------|
| MUCIT REF | MUP-KCB-0042 | DIMENSIONS | 25,5X76X82 |
| OEM NO | 381 317 1712 | | |
| ENGINE TYPE | 1013/KO-1017/F-1019F/AF-1213-1217L-1219F/AF-1222/F/L/AF-1224AF-1225AF-1226AF-1227AF/LAF-1228AF-1231AF-1234AF-1414-1419L/F-1422F-1424F-1425F/AF-1426F-1427F-1428F/AF-1429F/AF-1431F-1442AF-1518/K-1521/AK/K/S-1613L-1617KO-1619KO-1622/L/L-1625/L/L-1626/L/K/AK-1627AF-1628L/L-1632/L/K/AK-1633L-1635K-1636L/K-1720L-1722/L/L-1726/L-1728-1729/L-1732L-1733L-1735-1817K/4X2-1821AK/K/4X4/4X2-1824-1922AK-1926/A-1928AK-1929/AK-1927AK-1932A-1935/S/L/AK/AK-1936K/AK-1938S/L-1945/AK/A/AF-1948AK-2024K/AK-2028A/6X6-2031A-2036A/6X6-2038A-2044LA-2050AF-2219K/6X4-2220L-2222L-2224/6X4-2225/L-2226L/6X2-2228A/L/F-2232L/6X2-2233L-2235K-2236L-2421-2422/L-2426/L-2428/AK-2429/L-2434L-2435-2436-2517/6X2-2521/6X2-2524/6X2-2528A-2529-2531/L-2535/AK-2536/AK/AK-2538-2544-2550-2553-2626A/K/AK-2628K/AK/AK-2629/AK/K/A-2631K-2632A/K/AK-2635/6X4/L/AK-2636/AK/AK/L-2637K/6X4-2645AF-2648K-2650/AS/AK/S-2653AK-2828-3028-3036-3050/S-3228-3236A-3244A-3250A/AF-3328L/K-3332-3336/B/K-3528K-3529-3535/K/L/AK--3536/K-3548/S-3550/S-3553/S-3820-3836AK-3850A/AF-4050A/8X8-4436-4648-4836-4850A/8X8-5035-5436-6036/AK | | |



REPAIR KIT FOR STABILIZER -REAR

| | | | |
|-------------|--|------------|--|
| MUCIT REF | MUP. 300582 | DIMENSIONS | |
| OEM NO | 620 320 0028 | | |
| ENGINE TYPE | 2544-2550-2622-2650A-3335A-3535L-3550L-3833-3835 | | |



REPAIR KIT FOR STABILIZER -FRONT

| | | | |
|-------------|--|------------|--|
| MUCIT REF | MUP. 300583 | DIMENSIONS | |
| OEM NO | 620 320 0628 - 619 320 0128 | | |
| ENGINE TYPE | 1635/S/K-1636/S/K-1638/S-1733/L-1928/S/K/AK-933/S-936/K/S-1938/S-2028S-2033S-2228/S/L/F/L-2233/S/6X4-2236/S/L/S-2238/S/6X4-2428-2438-2628/B/S/K-2633/S/L-2636/L/K/S/L-2638/L/L/K/L/S-2828-2833-3028/B/K-3033/B/K-3036-3038-3228-3235-328/B/K-3333/B/K-3336/B/K/S-3338-3528-3535/B/K/L-3536/K/S-3636-3833-4436-1722/L-1726/K/L-1728-1729/K/S-1735/K/S/AF-1748/S-1831/K-1834/K/S-1838/S/K-1844/K-1350/K/S-1922/K/S/AK/LK-1927AK-1929/AK/AS-1935/S/AS/K/LAS-1944/S-1945/AK/A948/AK-2024K/AK-2027AK-2031A/K/AS-2035S-2038/A/AS/LAS-2044/AS/LAS-2050A/AF-2055AF-2219C-2220/L-2222-2235/S/L/S/K-2429/K/S/L-2433-2435/L/S/L-2444/L-2448/S/L-2529-2531/L-2535/K/L/S-2538/F/L/S/L/K/L-2544/L/S/L/K/L-2550/L/K/S/L-2553-2622-2629/A/B/K/S-2631/K/L/K/S/L-2634/S-2635/S/L/S/LK-2644/L/S/L/K/LK-2648/S/L/S/K-2650A/L/K/S/L-2653/L/S/L-3035-3238-3244-3248-3335/K-3344-3529-3538-3544/K/S-3548S-3550/S/L-3553/S/L-3835-4044S-4150K-4435-4635-4644-4844S-5035S-5248K | | |



REPAIR KIT FOR STABILIZER -FRONT

| | | | |
|-------------|--|------------|--|
| MUCIT REF | MUP. 300584 | DIMENSIONS | |
| OEM NO | 621 320 0228 | | |
| ENGINE TYPE | 1245A-1424LAP-1729AK-1735AK-1831AK-1834AK-1835-1838-1844-1850-1853-1922AK-1925AK-1926AK, 4X4-1927AK-1928A/AK/AS/K-1929A/AS/AK-1935A/AS/AK/LAS-1936A/AS/AK/LAS-1945A/AF/AK/AF-1948AK-2024AK/LAK-2027AK-2031A/AS/LAS-2038A/AS/LAS-2044LA/LAS/AS-2050AF-2228A-2428A-2435-2528A/AK-2529-2531/L-2535/A/K-2536/A/K/AK-2538-2544-2550-2553-2628A/AS-2629A/AS-2631A/AS/2635A/LAS-2636/AS-2638A/LA/LAS-2644A/AS-2645A/AF-2648AS-2650A/AS-2653AS-3036-3235AK-3328B/K-3335A/AK-3336-3528K-3535A/K/L/AK-3536-3538/K/AK-3544S/K/AK-3548-3550/L/K/AK-4050A/8X8-4436-4445-46354644-4645-4648-4844/K-4850A/8X8-4853-5035-5038-5436-6030/AK | | |



REPAIR KIT FOR STABILIZER -FRONT

| | | | |
|-------------|---|------------|--|
| MUCIT REF | MUP. 300585 | DIMENSIONS | |
| OEM NO | 621 320 0428 | | |
| ENGINE TYPE | 1628/L/S-1633/L/S-1635/L/S-1636L/S-1638L/S-1644/L/S-1729/L/S-1735/L/S/K-1748/L/S-1831/L/S-1834/L/S-1838L/S-1844/L/S-1850L/S/LAS/K-1928L/S-1929L-1933L/S-1935L/S-1938L/S-1944L/S-2028L/S-2033L/S-2035L/S-2036L/S-2228L-2233L-2238L-2235L-2236L/S-2238L-2244L/S-2428L-2429L/S-2433L-2434L-2435L/S-2444L/S-2448L/S-2531L-2534L-2535L-2538L/S-2544L/S-2550L/S-2553L/S-2650/S/L-3038L-3050/S-3235L-3238L-3244L-3250L-3548/S-3550/S-3553S | | |



REPAIR KIT FOR STABILIZER -FRONT



| | | |
|-------------|---|------------|
| MUCIT REF | MUP. 300586 | DIMENSIONS |
| OEM NO | 624 320 0028 - 625 320 0028 | |
| ENGINE TYPE | 2228A-2428A-3328/B/K-3528/K-3535-3536AK-3820-3850A-4436AK-4445-4645-5436AK-6036AK-1245A-1928/A/K/AS/K-1935A/AK-1936A/AK/AS/LAS-1945A/F/AF-2436/A/AK/KA-2528/A/AK-2535A-2536/A/AK/K-2628/A/AS-2636/A/AS-2645AF-3036/K-3335-3336/A/AK | |

REPAIR KIT FOR STABILIZER -FRONT



| | | |
|-------------|---|------------|
| MUCIT REF | MUP. 300587 | DIMENSIONS |
| OEM NO | 625 320 0611 | |
| ENGINE TYPE | 2524L-2527/L/S/K/B-2531/L/B-2534/L/K/S/LS-2635A-3239/B/K-3233/B/K-3234/B/K/L3535/AK-4635-4844 | |

REPAIR KIT FOR STABILIZER -FRONT



| | | |
|-------------|--|------------|
| MUCIT REF | MUP. 300588 | DIMENSIONS |
| OEM NO | 647 320 0028 | |
| ENGINE TYPE | 2035S/6X2/4-2429S/6X2/4-2435S/6X2/4-2538S-3028/B/K-3050-3053/A-3228/B/K-3235/K-3238/L-3244-3250-3253-3328/K-3528/B/K-3534K3535/K/B/AK-3538/K/AK-3544K-3548K-3550-4435K | |

REPAIR KIT FOR STABILIZER -FRONT



| | | |
|-------------|---|------------|
| MUCIT REF | MUP. 300589 | DIMENSIONS |
| OEM NO | 620 320 0428 - 620 320 0232 - 620 586 0232 | |
| ENGINE TYPE | 1628/S/L-1633/S/L-1635S-1636/L/S-1638/S-1733L-1928/S/K-1933/S-1936/K/S-1938/S-2028S-2033S-2228/S/L/F/LS-2233/S/6X4-2236/S/L/LS-2238/S/6X4-2428-2443-2438L-2628/B/S/K-2633/S/LS-2636/L/K/S/LS-2638S-2828-2833-3028/B/K/8X4/4-3033/B/K-3036-3038-3228/K/L-3235/K-3328/B/K/8X4/4-3333/B/K-3336/B/K/S-3338-3528/B/K-3535/B/K-3536/K/S-3636-3833-4436-4836 | |

REPAIR KIT FOR STABILIZER -FRONT



| | | |
|-------------|--|------------|
| MUCIT REF | MUP. 300590 | DIMENSIONS |
| OEM NO | 620 320 0228 - 620 586 0032 | |
| ENGINE TYPE | 1626/S-1632/S-1926/K/S-1932/K/S-2026S/6X2/4-2032S/6X2/4-2226/S/6X2/4-2232/S/6X2/4-2626/B/K/S-2632/K/S/6X4-3332-LS1924-LS1928 | |

REPAIR KIT FOR STABILIZER -FRONT



| | | |
|-------------|---|------------|
| MUCIT REF | MUP. 300591 | DIMENSIONS |
| OEM NO | 620 320 0128 | |
| ENGINE TYPE | 1628L/LS-1633L/LS-1636L/LS-1638LS-1733L-1928L/LS-1933LS-1936LS-1938LS-2028LS/6X2/4-2033LS/6X2/4-2033LS-2036LS/6X2/4-2228L-2233L/6X2-2236L/LS-2238L-2428L-2433L-3025B/K8X4/4-3028/K/B-3038L-3228/K/L-3235/K-3238-3244-3250-3253-3328/K-3528/K/B-3535/B/K-3538/K-3544/K-3548K-4435K | |

REPAIR KIT FOR STABILIZER -FRONT

| | | |
|-------------|---|------------|
| MUCIT REF | MUP. 300592 | DIMENSIONS |
| OEM NO | 619 320 0028 | |
| ENGINE TYPE | 2219 C 6X2/4-1922/K/S/AK-1925AK-1928A/AK/AS-2025S/6X2/4 2220-2222-2225-2422-2622 | |



REPAIR KIT FOR STABILIZER -REAR

| | | |
|-------------|---|------------|
| MUCIT REF | MUP. 300593 | DIMENSIONS |
| OEM NO | 617 320 0128 | |
| ENGINE TYPE | 1222/F/S-1228/F-1414/K-1417 C/CS/CK-1419 C/CL-1420/L/LS-1422/F/L/LS/S/LL- 1425/LS/S/L/F-1428 F-1429 F-1614/K/L-1617/C/CK/CL/CS-1619 C-1620/K/L/LL- 1622/K/L/S/LL/LS-1625/L/LS/LL/S/K-1628/L/LL-1733 L-1814-1919 C-2219 6X2/4/C/CL/6X2- 2220/CL/6X2/L-2222/L/B/K/L/6X2-2225/L/B-2228/L/LL-2422-2425/L-2428 L-2432 L- 2433 L-2822-2825-2828-3025/K/B-3028/B-3228/B/K-3233/B-3235-3328-3528- 3535 | |



REPAIR KIT FOR STABILIZER -FRONT

| | | |
|-------------|-----------------------------|------------|
| MUCIT REF | MUP. 300594 | DIMENSIONS |
| OEM NO | 617 320 0611 | |
| ENGINE TYPE | 3025/K-3028-3228/K/B-3233/B | |



REPAIR KIT FOR STABILIZER -FRONT

| | | |
|-------------|---|------------|
| MUCIT REF | MUP. 300595 | DIMENSIONS |
| OEM NO | 393 320 0128 - 393 586 0132 | |
| ENGINE TYPE | 1626AK/AS-1632AK/AS-1926A/AK/AS-1932A/AK/AS-2626A/AB/AS/6X6 2632A/AS/6X6-2232L/6X2-2226L/6X2 | |



REPAIR KIT FOR STABILIZER -FRONT

| | | |
|-------------|----------------------|------------|
| MUCIT REF | MUP. 300596 | DIMENSIONS |
| OEM NO | 389 320 0128 | |
| ENGINE TYPE | 1719-1919-2219 6X2/4 | |



REPAIR KIT FOR STABILIZER -FRONT

| | | |
|-------------|---|------------|
| MUCIT REF | MUP. 300597 | DIMENSIONS |
| OEM NO | 393 320 0328 - 393 586 0432 | |
| ENGINE TYPE | 1626AS/AK-1632AS/AK-1926A/AS/AK-1932A/AS/AK-2228L-2428L-2433L-2626A/AS/AB- 2632A/AS-3235L-2226L/6X2-2232L/6X2-2233L/6X2-2235L-2236L/LS-2238/L- 2244L/LL-2429L-2434L-2435L/LS-2448L/LS-2532L-2535L-2538L-2544L-2550L- 3036L-3238L-3244L-3250L | |



REPAIR KIT FOR STABILIZER -FRONT



| | | |
|-------------|-----------------------|------------|
| MUCIT REF | MUP. 300598 | DIMENSIONS |
| OEM NO | 389 320 0028 | |
| ENGINE TYPE | 1719/AK/S-1919/K/AK/S | |

REPAIR KIT FOR STABILIZER -REAR



| | | |
|-------------|--|------------|
| MUCIT REF | MUP. 300599 | DIMENSIONS |
| OEM NO | 387 320 0428 - 387 586 0432 | |
| ENGINE TYPE | 1626LS-1632L/LS-1926LS-1932LS-2226/L 6X2-2226/S/LS 6X4-2232/LS 6X4 | |

REPAIR KIT FOR STABILIZER -FRONT



| | | |
|-------------|--|------------|
| MUCIT REF | MUP. 300600 | DIMENSIONS |
| OEM NO | 387 320 0028 - 387 586 0032 - 000 323 3785 S | |
| ENGINE TYPE | | |

REPAIR KIT FOR STABILIZER -REAR



| | | |
|-------------|--|------------|
| MUCIT REF | MUP. 300601 | DIMENSIONS |
| OEM NO | 346 320 0128 S - 346 586 0132 S - 000 326 0981 S | |
| ENGINE TYPE | LP/LPS 1418-LP/LPS 1424-LP/LPK/LPS 1624-LP/LPK/LPS 1626-LP/LPK/LPS 1632-LP 1636-LP/LPS 1924-LP/LPS 1926-LP/LPS 1932-LPS 2024/6X2-LPS 2032/6X2-LP/LPK/LPS 2224/6X4-LP/LPK/LPS 2226/6X4-LP/LPK/LPS 2232/6X2/6X4-LS 1624-L/LA/LS 1924 | |

REPAIR KIT FOR STABILIZER -REAR



| | | |
|-------------|--|------------|
| MUCIT REF | MUP. 300602 | DIMENSIONS |
| OEM NO | 360 320 0341 - 360 586 0332 | |
| ENGINE TYPE | 11130F-13130F-13170F-14130F-14170F-16170F-16210F | |

REPAIR KIT FOR STABILIZER -REAR



| | | |
|-------------|-----------------------------|------------|
| MUCIT REF | MUP. 300603 | DIMENSIONS |
| OEM NO | 385 320 0128 - 385 586 0432 | |
| ENGINE TYPE | 2219 LP 6X2 -BM360-BM385 | |

REPAIR KIT FOR STABILIZER -REAR

| | | |
|-------------|--|------------|
| MUCIT REF | MUP. 300604 | DIMENSIONS |
| OEM NO | 387 320 0128 - 387 586 0132 - 000 326 1681S | |
| ENGINE TYPE | 1626/AK/AS/K/S-1632/AK/AS/K/S-1719/AK/K/S-1919/AK/K/S-1926/A/AK/AS/K/S 1932/A/AK/AS/K/S-2026S/6X2/4-2032S/6X2/4 | |



REPAIR KIT FOR STABILIZER -REAR

| | | |
|-------------|--|------------|
| MUCIT REF | MUP. 300605 | DIMENSIONS |
| OEM NO | 387 320 0528 - 387 586 0532 | |
| ENGINE TYPE | 1626/AK/AS/K/S-1632/AK/AS/K/S-1719/AK/K/S-1919/AK/K/S-1926/A/AK/AS/K/S 1932/A/AK/AS/K/S-2026S/6X2/4-2032S/6X2/4 | |



REPAIR KIT FOR STABILIZER -FRONT & REAR

| | | |
|-------------|--|------------|
| MUCIT REF | MUP. 300606 | DIMENSIONS |
| OEM NO | 314 326 0481S | |
| ENGINE TYPE | L 406DG/407D/408G/409L/410/508DG/608D- LK 406DG/407D/408G/409/410/508DG/608D- LF 408G/409/410-LP 808/809/811/813/913- LKO 406DG/407D/408G/409/508DG-LPO 808/809/811/813/608/709- LPS608/709/811/813/913- LPK 808/809/811/813/913- LPKF 608/709/808/809-LPKO 608/709- 0 309 D/B | |



REPAIR KIT FOR STABILIZER -REAR

| | | |
|-------------|--|------------|
| MUCIT REF | MUP. 300607 | DIMENSIONS |
| OEM NO | 625 320 0411 | |
| ENGINE TYPE | 1245A-1424LAP-1729AK-1735AK-1831AK-1834AK-1835-1838-1844-1850-1853-1922AK-1925AK- 1926AK,4X4-1927AK-1928A/AK/AS/K-1929/A/AS/IAK-1935/A/AS/IAK/LAS-1936A/AS/AK/LAS-1945/A/AF/IAK/AF- 1948AK-2024AK/LAK-2027AK-2031A/AS/LAS-2038/A/AS/LAS-2044LA/LAS/AS-2050AF-2228A-2428A- 2435-2528A/AK-2529-2531/L-2535/A/IK-2536/A/IK/IAK-2538-2544-2550-2553-2628/A/AS-2629A/AS- 2631A/AS/2635A/L/AS-2636/AS-2638A/LA/LAS-2644A/AS-2645AS/AF-2648AS-2650A/AS-2653AS-3036- 3235AK-3328B/K-3335/A/IAK-3336-3528/K-3535/A/IK/L/IAK-3536-3538/K/IAK-3544S/IK/IAK-3548- 3550/L/IAK-4050A/8X8-4436-4445-46354644-4645-4648-4844/IK-4850/A/8X8-4853-5035-5038- 5436-6030/AK | |



REPAIR KIT FOR STABILIZER -REAR

| | | |
|-------------|--|------------|
| MUCIT REF | MUP. 300608 | DIMENSIONS |
| OEM NO | 393 320 0228 - 393 586 0332 | |
| ENGINE TYPE | 2226 6X2,6X4-2226S 6X4-2232/S 6X2, 6X4 | |



REPAIR KIT FOR STABILIZER -REAR

| | | |
|-------------|---|------------|
| MUCIT REF | MUP. 300635 | DIMENSIONS |
| OEM NO | 617 320 0028 | |
| ENGINE TYPE | 1222AF/F/S-1225AF-1228F-1414K-1417CAK/CK-1422F/S-1425AF/S-1614K 1617CAK/CK/CS-1622AK/K/S-1625AK/K/S-2025S/6X2/4-2219C/6X2/4-2220-2222-2225 | |



REPAIR KIT FOR STABILIZER -REAR



| | | |
|-------------|---|------------|
| MUCIT REF | MUP. 300610 | DIMENSIONS |
| OEM NO | 617 320 0228 | |
| ENGINE TYPE | 1222AF/F/S/LS-1225AF-1228F-1414K-1417CAK/CK-1422F/S-1425F/AF/S-1428F/AF-1429F/AF-1614K-1617CAK/CK/CS-1620K-1622AK/K/S/A/LS-1625AK/K/S-1717K/IAK-1720S-1722K/IAK-1726 AK/K/S-1733L/LS-1820K/IAK-1824K/IAK/LAK-1827K/ISAK-1831/LAS-1834S-2025S/6X2/4-2219C/6X2/4-2220 6X2,6X4-2222/K-2225-2228-2433/S | |

REPAIR KIT FOR STABILIZER -REAR



| | | |
|-------------|---|------------|
| MUCIT REF | MUP. 300611 | DIMENSIONS |
| OEM NO | 620 320 0328 - 620 586 0132 | |
| ENGINE TYPE | 2219/L/CL 6X2-2220L 6X2-2222L 6X2-2225L 6X2-2228L 6X2-2420L-2422L-2427L-2433L-2435-2448-2524/L-2527/L-2531L-2534L-2550-3234L-3248 | |

REPAIR KIT FOR STABILIZER -REAR



| | | |
|-------------|--|------------|
| MUCIT REF | MUP. 300612 | DIMENSIONS |
| OEM NO | 623 320 0041 - 623 586 0032 | |
| ENGINE TYPE | 2228/L/F/LS/S-2233/S/6X4-2235/S/LS-2236/S/LS-2238S/6X4-2429/S/LS-2435/L/S/LS-2448/S/LS-2444/S/LS/6X4-2429/S/LS-2435-2448-2535LS-2538/K/L/S/LS-2544/L/S-2550/L/S/LS-2553/S/LS-2635-2828-2833-3028/B/K-3033B/K-3035-3228-3235-3238/L-3244-3248-3250-3255-3328-3333K-3335/K | |

REPAIR KIT FOR STABILIZER -REAR



| | | |
|-------------|---|------------|
| MUCIT REF | MUP. 300613 | DIMENSIONS |
| OEM NO | 625 320 0111 | |
| ENGINE TYPE | 2544K-3028/K-3228/K/L-3235/K/IAK-3238/L-3244-3250-3253-3328/K-3528/K/B-3535/B/K-3544/K-3548K-3550/K/IAK-4435K-4844/K-4850-4853-5038AK | |

REPAIR KIT FOR STABILIZER - FRONT



| | | |
|-------------|---|------------|
| MUCIT REF | MUP. 300621 | DIMENSIONS |
| OEM NO | 625 320 0511 | |
| ENGINE TYPE | 3235AK-3535AK-3538AK/K-3544K/IAK-3550AK-4844-4850-4853-5038AK | |

REPAIR KIT FOR STABILIZER - FRONT



| | | |
|-------------|--|------------|
| MUCIT REF | MUP. 300622 | DIMENSIONS |
| OEM NO | 625 320 0711 | |
| ENGINE TYPE | 3028/K-3228/K/L-3235/K-3238/L-3244-3250-3253-3328/K-3528/B/K-3538/K/IAK-3544/K/S-3548K-3550/K-4844/K-4850-4853 | |

REPAIR KIT FOR STABILIZER - FRONT

MUCIT REF MUP. 300623
 OEM NO 655 320 0111
 ENGINE TYPE 1722L-1733L-1834L-2420L-2422/L-2426L-2433L/LS-2522L
 2524L-2527L-2531L-2534L/LS/LI

DIMENSIONS



REPAIR KIT FOR STABILIZER

MUCIT REF MUP. 300624
 OEM NO 435 320 0228 - 435 586 0032
 ENGINE TYPE 2232 I/6X2-2226 I/6X2

DIMENSIONS



REPAIR KIT STABILIZER

MUCIT REF MUP. 300647
 OEM NO 363 320 0228
 ENGINE TYPE

DIMENSIONS



REPAIR KIT STABILIZER

MUCIT REF MUP. 300648
 OEM NO 387 320 0228
 ENGINE TYPE

DIMENSIONS



REPAIR KIT STABILIZER

MUCIT REF MUP. 300650
 OEM NO 393 320 0028
 ENGINE TYPE

DIMENSIONS



REPAIR KIT STABILIZER

MUCIT REF MUP. 300651
 OEM NO 346 320 0028
 ENGINE TYPE

DIMENSIONS



REPAIR KIT FOR STABILIZER



MUCIT REF MUP. 300712
OEM NO 435 320 0428
ENGINE TYPE

DIMENSIONS

REPAIR KIT FOR STABILIZER – REAR



MUCIT REF MUP. 300621
OEM NO 652 320 0511
ENGINE TYPE 1420L/LS-1422L/LS-1424L/LS-1426LS-1427L/LS-1431LS-1717L-1720L-1722L/LL-1729L/LS-1733L/LS-1735L/LS-1820L-1824L-1827L/LS-1831L/LS-1834L/LS-1838L/LS-1844L/LS-1850L-2320L-2327L-2420L-2422L/L-2426L/2427L-2429L-2433L/LS-2434L-2435L/LS-2448L/LS-2522L-2524L-2527L/L-2531L-2534L/LS-2538L-2544L/LS-2550L-3231L-3234L-3238L-3250L

DIMENSIONS

REPAIR KIT FOR STABILIZER – REAR



MUCIT REF MUP. 300615
OEM NO 621 320 0011
ENGINE TYPE 1748L/LS-1831L/LS-1834L/LS-1838L/LS-1844L/LS-1850L/LS/LAS-1928L/LS-1929L-1933L-1936L-1938L-1935L-1944LS-2228L-2244LS-2429L/LS/6X2/4-2434L-2435L/LS/6X2/4-2444LS-2448L/LS-2531L-2534L-2535L-2538L/LS-2544L/LS-2550L/LS-2553LS-2650L-3235L-3238L-3244L-3250L

DIMENSIONS

REPAIR KIT FOR STABILIZER – REAR



MUCIT REF MUP. 300616
OEM NO 620 320 0111
ENGINE TYPE 1628L-1633L/LS-1636LS/L-1635L/L-1638LS-1644L/LS-1729L/LS-1733L-1735L/LS-1748L/LS-1831LS-1834LS-1838L/LS-1844L/LS-1850L-2028LS/6X2/4-2035 LS/6X2/4-2033LS/6X2/4-2036LS/6X2/4-2228L-2233L-2235L-2236L/LS-2244L/LL/LS-2428L-2429LS/6X2/4/L-2433L-2435L/LS/6X2/4-2444LS-2448L/LS-2538LS/L-2544LS/L-2550LS/L-2553L-2650L-3038L-3235L

DIMENSIONS

REPAIR KIT FOR STABILIZER – REAR



MUCIT REF MUP. 300617
OEM NO 393 320 0428 - 393 586 0532
ENGINE TYPE 2226 S/LS/6X4-2232 S/ LS/6X4

DIMENSIONS

REPAIR KIT FOR STABILIZER – REAR



MUCIT REF MUP. 300618
OEM NO 387 320 0328 - 387 586 0332
ENGINE TYPE 1419CL-1420L-1422L/LS-1425LS-1617CL-1620L-1622L-1625L/LS-1626L/LS-1628L/LS-1632L/LS-1633L/LS-1635L/LS-1636L/LS-1638LS-1644LS-729L/LS-1733L-1735L/LS/LK-1748L/LS-1838L/LS-1844L/LS-1850K/L/LS/LAS-1935LS-1944LS-2028LS/6X2/4-2033LS/6X2/4-2035LS/6X2/4-2036LS/6X2/4-2219CL/6X2-2220L/6X2-2222L/6X2-2225L-2226 L/6X2-2228L/6X2-2232L/6X2-2233L/6X2-2235L-2236L-2238L-2244LS/L/LL-2429L/LS 6X2/4-2434L-2435L/L/LS 6X2/4-2438L-2448L/LS-2535L-2538L-2544L/LS-2550L-2553LS-2650L-3038L-3235L-3238L-3250L

DIMENSIONS

REPAIR KIT FOR STABILIZER - REAR

| | | |
|-------------|--|------------|
| MUCIT REF | MUP. 300619 | DIMENSIONS |
| OEM NO | 380 320 0028 - 380 586 0032 | |
| ENGINE TYPE | 1017LS-1217L/LS-1419L/LS/CL-1420L/LS-1422L/LS/LL1424L/LS-1425L/LS-1613L-1617L/CL-1619L-1620L/LL-1622L/LL-1624L/LS-1625L/LS/LL-1628L/LL-1733L-2219L 6X2-2222L-2225L-2425L-2428L | |



REPAIR KIT FOR STABILIZER - REAR

| | | |
|-------------|---|------------|
| MUCIT REF | MUP. 300620 | DIMENSIONS |
| OEM NO | 621 320 0128 | |
| ENGINE TYPE | 1926LS-1928L/LS-1929L-1932LS-1933LS-1935LS-1936LS-1938LS-1944LS-2244LS-2444LS-2448L-2429L | |



REPAIR KIT FOR STABILIZER - FRONT

| | | |
|-------------|---|------------|
| MUCIT REF | MUP. 300627 | DIMENSIONS |
| OEM NO | 360 320 0041 - 360 586 0032 | |
| ENGINE TYPE | 910LP-911B/LP/LA/LT-1013/LP-1017/L-1019-1113B/LP-1213/K/KO/S-1217/K/KO/L/LS-1219/F/K/S-1313L-1317OF/LP1413OF-1417-1419/L-1424/L-1513L/LA/LS/LKO/LK/LP-1517L/LA/LP-1519L/LA/LP-1613/L-1617L/OF-1619/L-1621OF-1624L/L/LS-2219L/LP/6X4-2224/ 6X2/4 | |



CABIN REPAIR KIT

| | | |
|-------------|---|------------|
| MUCIT REF | MUP. 300654 | DIMENSIONS |
| OEM NO | 620 310 0177 | |
| ENGINE TYPE | 2236L-2238L/LS-2244L/LL/LS-2422L-2425L-2426L-2428L-2433-2435L/LS-2438L-2444L/LS-2448L/LS-2535L-2538L/LS-2544L/LS-2550L/LS-2553L/LS-2633L/LS-2635L/LS-2638L/LS-2644L/LS-2648L/LS-2650L/LS-2653L/LS-2833-3033B/K-3035-3038L-3235L-3238L-3244L-3248-3250L-3253-3255-3333B/K-3335L-3338-3344-3544S/K-3548S-3550S-3553S/L-3833-4044S-4844S-5053S-5248K | |



REPAIR KIT FOR CABIN SUPPORT

| | | |
|-------------|--|------------|
| MUCIT REF | MUP. 300661 | DIMENSIONS |
| OEM NO | 387 586 0531 - 387 891 0957 | |
| ENGINE TYPE | 1619L-1622L/LL-1624L-1625L/LL-1628L/LL/LS-1633S/LS-1636L-1638L/LS-1928S/L/LS-1933L/LS-1936-1938S/LS-2028L-2033S/LS-2225L-2228S/L-2233S/L-2236L-2238L/LS-2425L-2428L-2423-2438L-2633S/LS-2638S-2833-3033B/K-3038L-3333B/K-3338-3833 | |



CABIN REPAIR KIT

| | | |
|-------------|--|------------|
| MUCIT REF | MUP. 300660 | DIMENSIONS |
| OEM NO | 387 310 0077 - 387 586 0131 | |
| ENGINE TYPE | 1619L-1622L/LL-1624L-1625L/LL-1628L/LL/LS-1633S/LS-1636L-1638L/LS-1928S/L/LS-1933L/LS-1936-1938S/LS-2028L-2033S/LS-2225L-2228S/L-2233S/L-2236L-2238L/LS-2425L-2428L-2423-2438L-2633S/LS-2638S-2833-3033B/K-3038L-3333B/K-3338-3833 | |



CABIN REPAIR KIT



MUCIT REF MUP. 300665

DIMENSIONS

OEM NO 318 586 0031

ENGINE TYPE 508 I-347-352-L 322-LA 322-LP 608/709/808/809/811/813/913/1013-LK 1921-LPK 608/709/808/809/811/813/913/1113-LPO 808/809/811/813-LPS 608/709/811/813-LPL 608/709/808/809/813/913/1113-LPKO 608/709-LPLS 608/709/813-LPKF 608/709/811/813

REPAIR KIT FOR CABIN SUSPENSION



MUCIT REF MUP. 300672

DIMENSIONS

OEM NO 381 586 0031

ENGINE TYPE

REPAIR KIT FOR CABIN SUSPENSION



MUCIT REF MUP. 300673

DIMENSIONS

OEM NO 620 586 0031

ENGINE TYPE 1013/KO-1017/F-1019F/AF-1213-1217L-1219F/AF-1222/F/L/AF-1224AF-1225AF-1226AF-1227AF/LAF-1228AF-1231AF-1234AF-1414-1419L-/F-1422F-1424F-1425F/AF-1426F-1427F-1428F/AF-1429F/AF-1431F-1442AF-1518K-1521/AK//K/S-1613L-1617KO-1619KO-1622/L/L-1625/L/L-1626/L/K/AK-1627AF-1628/L/L-1632/L/K/AK-1633L-1635K-1636L/K-1720L-1722L/L-1726L-1728-1729L-1732L-1733L-1735-1817K/4X2-1821AK/K/4X4/4X2-1824-1922AK-1926A-1928A/AK-1929A/AK-1927AK-1932A-1935S/LS/A/AK-1936K/A/AK-1938S/LS-1945/AK/A/AF/F-1948AK-2024/K/AK-2028A/6X6-2031A-2036A/6X6-2038A-2044LA-2050AF-2219KO/6X4-2220L-2222L-2224/6X4-2225L-2226L/6X2-2228/A/L/F-2232L/6X2-2233L-2235K-2236L-2421-2422L-2426L-2428/AK-2429L-2434L-2435-2436-2517/6X2-2521/6X2-2524/6X2-2528/A-2529-2531L-2535/A/K-2536/A/AK/K-2538-2544-2550-2553-2626/A/K/AK-2628/K/A/AK-2629/AK/K/A-2631K-2632/A/K/AK-2635S/6X4/L/AK-2636/AK/A/K/L-2637K/6X4-2645AF-2648K-2650/AS/A/AK/S-2653AK-2828-3028-3036-3050/S-3228-3236A-3244A-3250A/AF-3328/L/K-3332-3336/B/K-3528K-3529-3535/K/L/AK--3536/K-3548/S-3550L/S-3553S/LS-3820-3836AK-3850A/AF-4050A/8X8-4436-4648-4836-4850A/8X8-5035-5436-6036A/K-

REPAIR KIT FOR GEAR SHIFT



MUCIT REF MUP. 300662

DIMENSIONS

OEM NO 385 268 1474

ENGINE TYPE 709K-809/K-0 814L/F/K/KO/LS-0 817L/F/K/L/LS/S-914/AK/K/KO-917AF-1013/A/AK/K/KO/S-1017/A/AF/AK/AS/F/K/KO/LS/S-1019AF-1114/AK/K/L/S-0 1114/L42/L49-1117/A/K/L/LS/S-0 1117/L-1120/AF/F/L/LS/S-0 1120/L-1213/A/AK/AKO/AS/K/KO/S-1217/A/AK/AS/K/KO/L/LS/S-1219/A/AF/AK/F/K/S-1222/A/AF/AS/F/L/S-1225AF-1228F-1314/AK/K/KO/L-1317/AK/K/L/LS/S-1320/L/LS/S-1413/A/AK/AKO/K/KO-1414/K-1417/A/AK/AKO/K/KO/C/CAK/CK/CS-1419/AK/AS/F/K/L/LS/S/C/CL-1420/L/S-1422/F/L/LS/S-1424/F/K/LS/S-1425AF/F/L/LS/S-1428AF-1514L-1517/K/L-1520/L-1613/K/KO/L-1614/K/L-1617/AK/K/KO/LS/S/C/CAK/CK/CL/CS-1619/A/AK/K/KO/LS/S/C-1620/K/L-1622/AK/K/L/LS/S-1624/K/L/LS-1625/AK/K/L/LAK/LS/S-1626/A/S/K/L/LS/S-1628/L/LS/S-1632-1633/L/LS/S-1635K-1636L/LS/S-1638/LS/S-1719/AK/K/S-1722L-1726/K/L/LS/S-1729AK/K-1733L/LS-1735K/AF-1814-1919/AK/K/S-1922/AK/K/S-1925AK-1926/A/AK/AS/K/LS-1928/A/AK/K/L/LS/S-1929A/AK/AS/K-1932/A/AK/AS/K/LS-1933/LS/S-1935/A/AK/AS/K-1936/A/AS/L/AS/LS/K/S-1938/LS/S-1945A-2025/S-2026S 6X2/4-2028S/L 6X2/4-2032S 6X2/4-2033S/L 6X2/4-2036S 6X2/4-2219 6X2/4, 6X2/L, 6X2-2020L-2222K/L/B-2224 6X2/6X4, B 6X4, K 6X4, S 6X4-2225/L/B-2226 6X2/L 6X2, 6X4/ LS 6X4, S 6X4, 2228A/L/LS/S-2232 6X2/L 6X2/6X4/S 6X4-2233S/L 6X2/S 6X4-2235K-2236L/S 6X4-2238S 6X4-2422-2425/L-2428/L/A-2433-2435-2436-2438/L-2528/A/AK-2529-2535A-2536/A/AK/K-2622-2626 6X4/B 6X4/K 6X4/S 6X4/A 6X6/AB 6X6/AK 6X6/AS 6X6-2628/A/AK/AS/B/K/S-2629A/AK/AS/B/K-2632 6X4/K 6X4/S 6X4/AK 6X6/AS 6X6-2633/LS/S-2635A/AK/AS/K-2636/A/AK/AS/K/LS/S-2638/S-2822-2825-2828-2833-3025/B/K-3028/B/K-3033-3036/K-3038/L-3228-3229B/K-3235-3236A 6X6-3250A 6X6-3328/B/K-3332-3333/B/K-3335A-3336A/AK/B/K/S-3338-3528-3535/AK/B/K-3536/AK/S-3636-3833-3850A 6X6-4435K-4436/AK-4445-4645

REPAIR KIT GEAR SHIFT LEVER

MUCIT REF MUP. 301001
OEM NO 655 268 0074 SP
ENGINE TYPE 1013-1017-1019-1213
 1217-1219-1413-1417
 1419-1424-1613-1617
 1619-1624-1626-3031



REPAIR KIT BRAKE SHOE PIN

MUCIT REF MUP. 300676
OEM NO 318 420 0182
ENGINE TYPE 0301-0402-914AK-917AF-
 1114/AK/K/L/S/A-
 1117/AK/L/S/L-
 1120/AF/F/L/S/L-
 1314/AK/K/KO/L-
 1317AK/K/L/S/S-1320/L/S/L-
 1514L-1517/K/L



REPAIR KIT BRAKE SHOE PIN

MUCIT REF MUP. 300677 **DIMENSIONS** 56X86/98X63
OEM NO 675 420 0082
ENGINE TYPE 817AF-917A/AF-1013/A/AK/K/KO/S-1017/A/AF/AK/AS/F/KO/L/S/S-1019F-1114A-
 1117A/AF-1120AF-1124AF-1213/A/AK/AKO/AS-1217/A/AK/AS/K/KO/L/S/L-
 1219F/K/S-1222/A/AF/F/S-1224AF-1225AF-1226AF-1234AF-1317S/L/S/A-
 1413/K/KO-1414K-1416-1417K/KO/C/CA/CAK/CK/A-1419/AK/F/K/L/S/S/C/CL-
 1420/L/L-1422/F/L/S/S/F-1424F/S/L-1425AF/L/S-1426S/L-1428AF/F-1520-
 1521AK-1524-1613/K/KO/L-1614/K-1617/K/KO/L/S/C/CAK/CK/CL/CS/A-
 1619/K/KO/L/S/C-1620/L-1622/AK/K/L/S/A-1624/K/L/S/S-1625/AK/K/L/S/S/A-
 1626/AK/K/L/S/S/A/AS-1632/AK/AS/K/L/S/S-1635/K/L/S/S-1636K/L/S/S-1638/L/S/S-
 1644/L/S/S-1717/L-1719/AK/K/S-1720/S/L/LU-1722/L/K/A-1724-1726-
 1729/AK/K/L/S/S-1735/K/L/S/S/AF-1748/L/S/S-1814-1816/L-1820A/L-1821/L-
 1824A/L-1827A/L-1831L/A-1834L-1838/A/L-1840-1844-1850A/LA/L-
 1919/AK/K/S-1922/AK/K/S-1926/AK/K/S/AS/A-1928/AK/K/AS/K/L/S/S-
 1929/AK/K/AS/K/L/S-1936/AK/K/AS-1944/L/S/S-1948-2024/A-2025 6X2/4-
 2026AK 6X6/S 6X2/4-2028K/S/L 6X2/4-2031/A-2032 6X2/4-2033L 6X2/4-
 2035S 6X2/4/L 6X2/4-2038/A-2044-2219C/CL/K/L 6X2/4-2222 6X4/B 6X4/K/L-
 2225/B/L-2226L 6X4/S 6X4-2228/L/6X2-2232L 6X4/S 6X4-2235/L/S/ 6X2-
 2238/S 6X4-2244L/S/ 6X2/ L 6X2-2420/L-2422



REPAIR KIT BRAKE SHOE PIN

MUCIT REF MUP. 300678 **DIMENSIONS**
OEM NO 395 420 0041
ENGINE TYPE 0303-0305/G-0307-0405/G/ST/UE-16170F-16210F-16220H-16250H/L-16280H/L



REPAIR KIT BRAKE SHOE PIN

MUCIT REF MUP. 300679 **DIMENSIONS**
OEM NO 307 420 4102
ENGINE TYPE 0303-0404-0305/G-0307-0405/G/ST/UE-0F1617-0F1621-0H1625L-0H1628L



REPAIR KIT BRAKE SHOE PIN

MUCIT REF MUP. 300680 **DIMENSIONS**
OEM NO 335 420 0039
ENGINE TYPE



REPAIR KIT ROLLER/BOLT



| | |
|-------------|--|
| MUCIT REF | MUP. 300355 |
| OEM NO | 307 420 0339 |
| ENGINE TYPE | 1213/K/IAKO/AS-1217/K/IAK/AS/K/KO/L/LS/S-1219/F/K/JS-1222/A/AF/IF/S-1224AF-1225AF-1226AF-1234AF-1317/LS/A-1413/K/KO-1414/K-1416-1417/K/KO/C/CA/CAK/CK/A-1419/AK/FF/K/L/LS/S/C/CL-1420/L/LS-1422/F/L/LS/S/IF-1424/F/S/L-1425AF/LS/S-1426S/LS-1428AF/IF-1520-1521AK-1524-1613/K/KO/L-1614/K-1617/K/KO/L/LS/S/C/CAK/CK/CL/CS/A-1619/K/KO/L/LS/S/C-1620/L-1622/AK/K/L/LS/A-1624/K/L/LS/S-1625/AK/K/L/LS/S/A-1626/AK/K/L/LS/S/A/AS-1632/AK/AS/K/L/LS/S-1635/K/L/LS/S-1636K/L/LS/S-1638/LS/S-1644/LS/S-1717/L-1719/AK/K/JS-1720/S/L/LU-1722/L/K/A-1724-1726-1729/AK/K/L/LS/S-1735/K/L/LS/S/AF-1748/L/LS/S-1814-1816/L-1820A/L-1821/L-1824A/L-1827A/L-1831/LA-1834/L-1838/A/L-1840-1844-1850A/LA/L-1919/AK/K/JS-1922/AK/K/JS-1926/AK/K/JS/AS/A-1928/AK/K/AS/K/L/LS/S-1929/AK/K/AS/K/L/LS-1936/AK/K/AS-1944/LS/S-1948-2024/A-2025S 6X2/4-2026AK 6X6/S 6X2/4-2028K/LS/S 6X2/4-2031/A-2032S 6X2/4-2033LS 6X2/4-2035S 6X2/4/LS 6X2/4-2038/A-2044-2219C/CL/K/L 6X2/4-2222 6X4/B 6X4/K/L-2225/B/L-2226LS 6X4/S 6X4-2228/L/6X2-2232LS 6X4/S 6X4-2235/LS/I 6X2-2238/S 6X4-2244LS/I 6X2/ L 6X2-2420/L-2422 |

DIMENSIONS

REPAIR KIT BRAKE SHOE PIN



| | |
|-------------|--|
| MUCIT REF | MUP. 300681 |
| OEM NO | 307 420 4002 - 395 420 0082 - 395 420 0242 |
| ENGINE TYPE | 817AF-917A/AF-1013/A/IAK/K/JS-1017/A/AF/IAK/AS/F/KO/LS/S-1019F-1114A-1117A/AF-1120AF-1124AF-1213/A/IAK/IAKO/AS-1217/A/IAK/AS/K/KO/L/LS/S-1219/F/K/JS-1222/A/AF/IF/S-1224AF-1225AF-1226AF-1234AF-1317/LS/A-1413/K/KO-1414/K-1416-1417/K/KO/C/CA/CAK/CK/A-1419/AK/FF/K/L/LS/S/C/CL-1420/L/LS-1422/F/L/LS/S/IF-1424/F/S/L-1425AF/LS/S-1426S/LS-1428AF/IF-1520-1521AK-1524-1613/K/KO/L-1614/K-1617/K/KO/L/LS/S/C/CAK/CK/CL/CS/A-1619/K/KO/L/LS/S/C-1620/L-1622/AK/K/L/LS/A-1624/K/L/LS/S-1625/AK/K/L/LS/S/A-1626/AK/K/L/LS/S/A/AS-1632/AK/AS/K/L/LS/S-1635/K/L/LS/S-1636K/L/LS/S-1638/LS/S-1644/LS/S-1717/L-1719/AK/K/JS-1720/S/L/LU-1722/L/K/A-1724-1726-1729/AK/K/L/LS/S-1735/K/L/LS/S/AF-1748/L/LS/S-1814-1816/L-1820A/L-1821/L-1824A/L-1827A/L-1831/LA-1834/L-1838/A/L-1840-1844-1850A/LA/L-1919/AK/K/JS-1922/AK/K/JS-1926/AK/K/JS/AS/A-1928/AK/K/AS/K/L/LS/S-1929/AK/K/AS/K/L/LS-1936/AK/K/AS-1944/LS/S-1948-2024/A-2025S 6X2/4-2026AK 6X6/S 6X2/4-2028K/LS/S 6X2/4-2031/A-2032S 6X2/4-2033LS 6X2/4-2035S 6X2/4/LS 6X2/4-2038/A-2044-2219C/CL/K/L 6X2/4-2222 6X4/B 6X4/K/L-2225/B/L-2226LS 6X4/S 6X4-2228/L/6X2-2232LS 6X4/S 6X4-2235/LS/I 6X2-2238/S 6X4-2244LS/I 6X2/ L 6X2-2420/L-2422 |

DIMENSIONS

SPRING PIN SET



| | |
|-------------|--|
| MUCIT REF | MUP. 300683 |
| OEM NO | 619 320 0065 |
| ENGINE TYPE | 2025S 6X2/4-2219 6X2/4/C 6X2/4-2220-2222-2225-3025-3028-3228 |

DIMENSIONS

SPRING PIN SET



| | |
|-------------|---|
| MUCIT REF | MUP. 300684 |
| OEM NO | 314 320 0365 - 314 586 0432 |
| ENGINE TYPE | 608LP/LPK/LPKF/LPKO/LPO/LPS-709LP/LPK/LPKF/LPKO/LPO/LPS-808LP/LPK/LPKF/LPKO-809LP/LPK/LPKF/LPKO-811LP/LPK/LPO/LPS-813LP/LPS-913LP/LPK |

DIMENSIONS

SPRING PIN SET



| | |
|-------------|---|
| MUCIT REF | MUP. 300685 |
| OEM NO | 322 320 0065 |
| ENGINE TYPE | 311L/LA-312L/LP-321LA/LAP-322L/LP/LPS/LS/LA/LAK/LAS-323L/LP/LPS/LS/LA 328L/LP/LPS/LS/LA/LAK |

DIMENSIONS

SPRING PIN SET



| | |
|-------------|--------------|
| MUCIT REF | MUP. 300686 |
| OEM NO | 338 320 0165 |
| ENGINE TYPE | 327L/LP |

DIMENSIONS

SPRING PIN SET

MUCIT REF MUP. 300687
 OEM NO 340 320 0364
 ENGINE TYPE 311L-312L

DIMENSIONS



SPRING PIN SET

MUCIT REF MUP. 300688
 OEM NO 358 320 0065
 ENGINE TYPE 810LP-911L/LP/LA/LT-1013LP-1017-1019-1113LP-1213LP-1216LP-1413
 1417-1419L-1424-1513L/LA/LP-1517L/LA/LP-1519L/LA/LP-1613-1617
 1619-1624-1813L-1817L-1819L-2216L-2224 6X2/4

DIMENSIONS



SPRING PIN SET

MUCIT REF MUP. 300689
 OEM NO 385 320 0165 - 385 586 0332
 ENGINE TYPE 810LP/LPF/LPK/LPS/LPKO-911B/LP/LPF/LPK/LPS/LPKO/L/LA/LAK/LAS-1621L/LK/LS-
 1624LAK/LAS/LK/LS-1626/AK/AS/K/S-1628/S-1632/AK/AS/K/S-1633/S-1635/K/S-
 1636/S-1638/S-1644/S-1719/AK/K/S-1728-1729/AK/K/S-1735/K/S/AF-1748/S-
 1919/AK/K/S-1922/AK/K-1926/A/AK/AS/K/S-1928/A/AK/AS/K/S-1929/A/AK/AS/K/S-
 1932/A/AK/AS/K/S-1933/S-1935/K/AK/AS/K/S-1936/K/AK/AS/K/S-1938/S-1944/S-
 1948-2026S 6X2-2028S-2032S 6X2/4-2033S-2035S 6X2-2222-2226 6X2/4/S-
 6X4-2228/6X2

DIMENSIONS



SPRING PIN SET

MUCIT REF MUP. 300690
 OEM NO 329 320 0265
 ENGINE TYPE 1618L/1620L/LA/LP/LPS/LS-1623L/LA/LP-1624LP-1920L/LA-2020LPS-2023LPS
 2024LPS-2223LP-2224LP 6X4

DIMENSIONS



SPRING PIN SET

MUCIT REF MUP. 300691
 OEM NO 352 320 0065
 ENGINE TYPE 1216LPK/LPS-1317LPK/LPS-1319LPK/LPS

DIMENSIONS



SPRING PIN SET

MUCIT REF MUP. 300692
 OEM NO 335 320 0065
 ENGINE TYPE

DIMENSIONS



SPRING PIN SET - REAR



| | | |
|-------------|-----------------------------|------------|
| MUCIT REF | MUP. 300693 | DIMENSIONS |
| OEM NO | 395 320 0265 - 395 586 0232 | |
| ENGINE TYPE | | |

SPRING PIN SET - FRONT



| | | |
|-------------|-----------------------------|------------|
| MUCIT REF | MUP. 301608 | DIMENSIONS |
| OEM NO | 395 320 0165 - 395 586 0332 | |
| ENGINE TYPE | | |

SPRING PIN SET



| | | |
|-------------|----------------------------|------------|
| MUCIT REF | MUP. 300694 | DIMENSIONS |
| OEM NO | 625 320 0065 | |
| ENGINE TYPE | 3025-3028/B-3228-3235-3535 | |

SPRING PIN SET



| | | |
|-------------|--|------------|
| MUCIT REF | MUP. 300695 | DIMENSIONS |
| OEM NO | 314 320 0065 - 314 586 0532 | |
| ENGINE TYPE | 608LP/LPK/LPKF/LPKO/LPO/LPS/LPL/LPLS-709LP/LPK/LPKF/LPKO/LPO/LPS/LPL/LPLS-808LP/LPK/LPKF/LPKO/LPO-809LP/LPK/LPKF/LPKO/LPO-811LP/LPK/LPO/LPS-813LP/LPK/LPL/LPLS/LPO/LPS-913LP/LPK/LPL/LPS-1013LP/LPK/LPL-1113LP/LPK/LPL | |

SPRING PIN SET



| | | |
|-------------|---|------------|
| MUCIT REF | MUP. 300696 | DIMENSIONS |
| OEM NO | 329 320 0065 | |
| ENGINE TYPE | 1518LAK-2624L/LB/LK/LS 6X4-2624LA/LAB/LAK/LAS 6X4 | |

SPRING PIN SET



| | | |
|-------------|--------------|------------|
| MUCIT REF | MUP. 300697 | DIMENSIONS |
| OEM NO | 338 320 0265 | |
| ENGINE TYPE | | |

SPRING PIN SET

MUCIT REF MUP. 300698
 OEM NO 361 320 0065
 ENGINE TYPE 1418LP-1424LP-2224LP / 6X4-2226LP-2232 6X4

DIMENSIONS



SPRING PIN SET

MUCIT REF MUP. 300699
 OEM NO 385 320 0065 - 385 586 0232
 ENGINE TYPE 13130F-13170F-14130F-14170F/OH-16170F/LP-1619LP/LPK0-16210F-16220H-16250H/L-16280H/L-2219LP/LPK 6X4 -2223LP 6X2- 2224LP 6X2

DIMENSIONS



SPRING PIN SET

MUCIT REF MUP. 300700
 OEM NO 622 320 0165
 ENGINE TYPE 2025S 6X2/4-2028LS 6X2/4-2033LS 6X2/4-2035LS 6X4/S 6X4-2036LS 6X2/4-2219C 6X2/4-220L 6X2/4-2222-2225-2429LS 6X2/4/S 6X2/4-2435S/LS 6X2/6X4

DIMENSIONS



SPRING PIN SET

MUCIT REF MUP. 300701
 OEM NO 622 320 0065
 ENGINE TYPE 2025S 6X2/4-2028LS 6X2/4-2033LS 6X2/4-2035LS 6X4/S 6X4-2036LS 6X2/4 2219C 6X2/4-220L 6X2/4-2222-2225-2429LS 6X2/4/S 6X2/4-2435S/LS 6X2/6X4

DIMENSIONS



SPRING PIN SET

MUCIT REF MUP. 300702
 OEM NO 389 320 0065 - 389 586 0132
 ENGINE TYPE 1624LP/LPK/LPS-1626LP/LPK/LPS-1632LP/LPK/LPS-1924LP/LPS-1926LP/LPS 2024LPS 6X2-2032LPS 6X2-2224LP 6X2-2226LP 6X2-2232LP/LPL 6X2

DIMENSIONS



SPRING PIN SET

MUCIT REF MUP. 300703
 OEM NO 648 320 0065
 ENGINE TYPE 2228/6X2-2233/6X2-2235/S-2236/6X2-2238-2244-2429-2433-2435-2438-2448-2538/K-2550-2628-2633-2635-2636-2644-3028-3033-3035-3036-3038-3235-3248-3355-3544

DIMENSIONS



SPRING PIN SET



MUCIT REF MUP. 300704

DIMENSIONS

OEM NO 658 320 0065

ENGINE TYPE 1245A-1628/S-1633/S-2635/S/K-1636/S-1638/S-1644/S/L-1650-1728-1729/AK/K/S-1735/AK/K/S/AF-1748/S-1922/AK/K/S-1924/L/LK/LS-1925/AK-1928/A/AK/AS/K/S/L/LK/LS-1929/K/S-1933/S-1935/A/AK/AS/S/K-1936/A/AS/K/LAS/S-1938/S-1944/S-1945A-1948-2028S-2033S-2035S 6X2/4-2222-2228/A-2233S-2235-2236-2422/K-2428/A-2429S 6X2/4-2433-2435/S 6X2/4-2436-2438L-2444L-2448-2528/A/AK-2535A-2536/A/AK/K-2622-2628-2635-2636L-2638-3028-3033-3035-3036-3038-3235-3248-3335/K-3833-3835

SPRING PIN SET



MUCIT REF MUP. 300705

DIMENSIONS

OEM NO 314 320 0165

ENGINE TYPE 311L-312L

SPRING PIN SET



MUCIT REF MUP/ 300706

DIMENSIONS

OEM NO 625 320 0165 - 624 320 0064

ENGINE TYPE 3028/B-3228-3235-3328-3528-3535/B/K-4435K

SPRING PIN SET



MUCIT REF MUP. 300707

DIMENSIONS

OEM NO 625 320 0265

ENGINE TYPE 3025/K-3026-3228/B/K-3233/B

SPRING PIN SET



MUCIT REF MUP. 300708

DIMENSIONS

OEM NO 389 320 0165 - 389 586 0232

ENGINE TYPE 2219/C-2220-2223/LP-2224/LP-2226/LP-2228-2232/LP/LPI-2233-2235-2236L-2238-2244-2433-2438-2628-2633-2635-2636/L-2638-2644-3028-3033-3036-3038-3335-3544

SPRING PIN SET



MUCIT REF MUP. 300709

DIMENSIONS

OEM NO 389 320 0265

ENGINE TYPE 1626/AK/AS-1632/AK/AS-1719/AK-1919/AK-1922/AK-1926/A/AK-1928/A/AK-1929/AK/A 1932/A/AK/AS-1935/AK-1936/AK-2528/A/AK-2529-2536/AK

AXLE ROD REPAIR KIT WITH BOLT

| | | | |
|-------------|--|------------|-------------|
| MUCIT REF | MUP. 300655 | DIMENSIONS | Q80XQ21X152 |
| OEM NO | 000 350 0213 - 000 586 1433 | | |
| ENGINE TYPE | 1617L-1619L-1624L/LS-1626L/LS-1628L/LS-1632L/LS-1633L/LS-1635L/LS-1636L/LS-1638L/LS-1644L/LS-1722L-1726L/LS-1729L/LS-1733L/LS-1735L/LS-1748L/LS-1926L/LS-1928L/LS-1929L-1932L/LS-1933L/LS-1935L/LS-1936L/LS-1938L/LS-1944L/LS-2028L 6X2/4-2033L 6X2/4-2035L 6X2/4-2036L 6X2/4-2219L/CL 6X2-2220L/L 6X2/4-2225L-2226L 6X2/LS 6X4-2228L-2232 LS 6X4- 2233L 6X2-2235L-2236L-2238L-2244L/LS 6X2/4-2429L-2435L-2448L-3025-3028-3228-3235L | | |



AXLE ROD REPAIR KIT WITHOUT BOLT

| | | | |
|-------------|--|------------|-------------|
| MUCIT REF | MUP/ 300656 | DIMENSIONS | Q80XQ21X152 |
| OEM NO | 000 586 1533 | | |
| ENGINE TYPE | 1617L-1619L-1624L/LS-1626L/LS-1628L/LS-1632L/LS-1633L/LS-1635L/LS-1636L/LS-1638L/LS-1644L/LS-1722L-1726L/LS-1729L/LS-1733L/LS-1735L/LS-1748L/LS-1926L/LS-1928L/LS-1929L-1932L/LS-1933L/LS-1935L/LS-1936L/LS-1938L/LS-1944L/LS-2028L 6X2/4-2033L 6X2/4-2035L 6X2/4-2036L 6X2/4-2219L/CL 6X2-2220L/L 6X2/4-2225L-2226L 6X2/LS 6X4-2228L-2232 LS 6X4- 2233L 6X2-2235L-2236L-2238L-2244L/LS 6X2/4-2429L-2435L-2448L-3025-3028-3228-3235L | | |



AXLE ROD REPAIR KIT WITH BOLT

| | | | |
|-------------|---|------------|-----|
| MUCIT REF | MUP/ 300657 | DIMENSIONS | Q80 |
| OEM NO | 343 586 0032 - 000 586 1633 | | |
| ENGINE TYPE | 1632LP/LPS-1813L 6X2/4-1817L 6X4-1819L 6X4-2219LP 6X2- 2232LPL 6X2-2624L/LB/LK/LS 6X4/LA/LAB/LAK/LAS 6X6- 1632-2219 | | |



AXLE ROD REPAIR KIT WITHOUT BOLT

| | | | |
|-------------|---|------------|-----|
| MUCIT REF | MUP/ 300658 | DIMENSIONS | Q80 |
| OEM NO | 000 586 0632 | | |
| ENGINE TYPE | 1632LP/LPS-1813L 6X2/4-1817L 6X4-1819L 6X4-2219LP 6X2- 2232LPL 6X2 2624L/LB/LK/LS 6X4/LA/LAB/LAK/LAS 6X6- 1632-2219 | | |



AXLE ROD REPAIR KIT WITH BOLT

| | | | |
|-------------|--|------------|--|
| MUCIT REF | MUP/ 300659 | DIMENSIONS | |
| OEM NO | 000 350 0405 - 000 586 1833 - 000 586 0135 - 000 586 1933 | | |
| ENGINE TYPE | 1017LS-1217L/LS-1419L/LS/CI-1420L-1422L/LS-1424LS-1425LS-1613L-1617L/CL-1619L-1620L-1622L-1624L/LS-1625L/LS-1626L/LS-1628L/LS-1632L/LS-1633L/LS-1635L/LS-1636L/LS-1638L/LS-1644L/LS-1722L-1726L-1729L/LS-1733L/LS-1735L/LS-1748L/LS-1926L/LS-1928L/LS-1929L-1932L/LS-1933L/LS-1935L/LS-1936L/LS-1938L/LS-1944L/LS-2028L 6X2/4-2033L 6X2/4-2036L 6X2/4-2219L/CL 6X2-2220L/L 6X2/4-2222L/L 6X2-2225L-2226L 6X2-2228L-2232L 6X2/LS 6X4-2233L 6X2-2235L-2238L-2244L 6X2-2425L-2428L-2429L 6X2/4-2435L 6X2/4-2448-2538L/LS-2550LS-3038L | | |



AXLE ROD REPAIR KIT

| | | | |
|-------------|--|------------|--|
| MUCIT REF | MUP. 300663 | DIMENSIONS | |
| OEM NO | 000 350 0205 | | |
| ENGINE TYPE | 1017LS1419L/LS/CI-1424LS-1613L-1617L-1619L-1624L/LS-1717L-1720L-1722L/LL-1726L/LL/LS-1729L/LS-1732L-1733L/LS-1734L-1820L-1824L-1827L/LS-1831L/LS-1834L/LS-2420L-2422L/L-2426L/L-2427L-2433L/LS-2434L-2522L-2524L/L-2527L/L-2531L-2534L/LL/LS-3231L-3234L | | |



AXLE ROD REPAIR KIT



MUCIT REF MUP. 300664
 OEM NO 000 586 1035
 ENGINE TYPE

DIMENSIONS

REPAIR KIT WITH BOLT



MUCIT REF MUP. 300670
 OEM NO 000 586 0132
 ENGINE TYPE

DIMENSIONS

REPAIR KIT WITHOUT BOLT



MUCIT REF MUP. 300670/1
 OEM NO 000 586 0732
 ENGINE TYPE

DIMENSIONS

REPAIR KIT WITH BOLT



MUCIT REF MUP. 302271
 OEM NO 000 350 1505
 ENGINE TYPE 1719/AK/S-19191824-1827-1831-2524-2527-2531-1729-1735 (Q90 mm) K/AK/S

DIMENSIONS

REPAIR KIT WITH BOLT



MUCIT REF MUP. 302270
 OEM NO 000 350 1405
 ENGINE TYPE 1831-1827-1824-2524-2527-2420-2429-2550 (Q80 mm)

DIMENSIONS

TENSION ROLLER FOR V-RIBBED BELT



MUCIT REF MUP-R-300856
 OEM NO 000 550 0433
 ENGINE TYPE 0M401-402-403-421-422-423-442-427

DIMENSIONS 80X44

TENSION ROLLER FOR V-RIBBED BELT

MUCIT REF MUP-R-300857
 OEM NO 442 200 0770
 ENGINE TYPE OM401LA-402LA-441LA-442LA

DIMENSIONS 95X35X40



TENSION ROLLER FOR V-RIBBED BELT

MUCIT REF MUP-R-300858
 OEM NO 000 550 0033
 ENGINE TYPE OM401LA-402LA-441LA-442LA

DIMENSIONS 95X50



TENSION ROLLER FOR V-RIBBED BELT

MUCIT REF MUP-R-302678
 OEM NO 601 200 0770
 ENGINE TYPE M104-103-102/OM602-601-M119

DIMENSIONS



RUBBER MOUNTING

MUCIT REF MUP-R-302679
 OEM NO 601 200 1070
 ENGINE TYPE M104-103-102/OM602-601-M119

DIMENSIONS



TENSION ROLLER FOR V-RIBBED BELT

MUCIT REF MUP-R-300855
 OEM NO 601 200 0970
 ENGINE TYPE M102-OM601/602

DIMENSIONS



VALVE COVER GASKET

MUCIT REF MUP-G-2045
 OEM NO 541 016 0321
 ENGINE TYPE OM501LA-502LA-(ACTROS)

DIMENSIONS

EXHAUST MANIFOLT GASKET



| | | |
|-------------|---|------------|
| MUCIT REF | MUP-G-2051 | DIMENSIONS |
| OEM NO | 403 142 0380 | |
| ENGINE TYPE | OM 401A-402-403-404/A-407A/HA/LA-409-421A/LA-422/A/LA-423/A/LA-424/A/LA-441/EURO1-442/EURO1-444A/LA | |

INTAKE MANIFOLT GASKET



| | | |
|-------------|---|------------|
| MUCIT REF | MUP-G-2057 | DIMENSIONS |
| OEM NO | 442 141 1780 | |
| ENGINE TYPE | OM 401A-402-403-404/A-407A/HA/LA-409-421A/LA-422/A/LA-423/A/LA-424/A/LA-441/EURO1-442/EURO1-444A/LA | |

INTAKE MANIFOLT GASKET



| | | |
|-------------|------------------------|------------|
| MUCIT REF | MUP-G-2059 | DIMENSIONS |
| OEM NO | 541 098 0480 | |
| ENGINE TYPE | OM501LA-502LA-(ACTROS) | |

STABILIZER BUSHING (LOWER-REAR)

| | | |
|-------------|---|------------|
| MUCIT REF | MUP.401204 | DIMENSIONS |
| OEM NO | 81 43704 0025 | |
| ENGINE TYPE | 16.192/200/240/280/290-19.240-26.240/281-32.240/365 | |



STABILIZER BUSHING UPPER

| | | |
|-------------|---|------------|
| MUCIT REF | MUP.401205 | DIMENSIONS |
| OEM NO | 81 43704 0026 | |
| ENGINE TYPE | 16.192-16.168-19.281-26.240-26.280-32.240 | |



STABILIZER BUSHING LOWER

| | | |
|-------------|--|------------|
| MUCIT REF | MUP.401206 | DIMENSIONS |
| OEM NO | 81 43704 0029 | |
| ENGINE TYPE | 12.222-14.170-15.168-17.232-18.272-19.240-26.281 | |



STABILIZER BUSHING REAR

| | | |
|-------------|-----------------------------|------------|
| MUCIT REF | MUP.401207 | DIMENSIONS |
| OEM NO | 81 43704 0032 | |
| ENGINE TYPE | 16.240-19.272-25.422-33.322 | |



ROLLER & BOLT-COMplete

| | | |
|-------------|--|------------|
| MUCIT REF | MUP.401728 | DIMENSIONS |
| OEM NO | 81 50213 6006S | |
| ENGINE TYPE | S1200-SR240/280-16.240/280-19.240/281-26.281 | |



BRAKE SHOE PIN REPAIR KIT

| | | |
|-------------|---|------------|
| MUCIT REF | MUP.401246 | DIMENSIONS |
| OEM NO | 81 50212 0032 S | |
| ENGINE TYPE | 18.224/264/370/420-19.403/463-41.322/372/422/502-48.372/422 | |



BALL JOINT REP.KIT REAR



| | | |
|-------------|---|------------|
| MUCIT REF | MUP.401238 | DIMENSIONS |
| OEM NO | 81 43220 6108 - 81 43220 6132 | |
| ENGINE TYPE | 19.242/262/272/322/362/372/422/462/502 FL | |

BALL JOINT REP.KIT REAR



| | | |
|-------------|--|------------|
| MUCIT REF | MUP.401241 | DIMENSIONS |
| OEM NO | 81 95301 6133 - 81 95301 6083 | |
| ENGINE TYPE | 16.168/170- 17.170/192- 18.220- 19.240/281- 22.230- 24.230/242- 26.281/293- 30.242 | |

BALL JOINT REP.KIT



| | | |
|-------------|---------------|------------|
| MUCIT REF | MUP.401247 | DIMENSIONS |
| OEM NO | 81 43270 6065 | |
| ENGINE TYPE | 14.280 | |

BALL JOINT REP.KIT REAR



| | | |
|-------------|---|------------|
| MUCIT REF | MUP.401926 | DIMENSIONS |
| OEM NO | 81 43270 6080 | |
| ENGINE TYPE | 16.240/280/360- 18.310- 24.350- 30.364- 19.403/423/463/464- TGA | |

BALL JOINT REP.KIT



| | | |
|-------------|--|------------|
| MUCIT REF | MUP.401240 | DIMENSIONS |
| OEM NO | 81 95301 6132 | |
| ENGINE TYPE | 14.170- 16.168/240- 19.262- 26.240/281/292- 32.322- 33.272/302/422 | |

BALL JOINT REP.KIT REAR



| | | |
|-------------|-------------------|------------|
| MUCIT REF | MUP.401925 | DIMENSIONS |
| OEM NO | 81 43250 6009 | |
| ENGINE TYPE | 8.136- 9.136- TGL | |

BALL JOINT REPAIR KIT

MUCIT REF **MUP.402097**
 OEM NO **81 43270 6047**
 ENGINE TYPE

DIMENSIONS



BALL JOINT (KIT)

MUCIT REF **MUP.402096**
 OEM NO **81 43230 6043**
 ENGINE TYPE

DIMENSIONS



SPRING PIN

| MUCIT REF | OEM NO | DIMENSIONS |
|------------|---------------|------------|
| MUP.401673 | 81 41306 0090 | 25X130 |
| MUP.401673 | 81 41306 0070 | 25X130 |
| MUP.401673 | 81 41306 0087 | 25X130 |
| MUP.401673 | 88 41306 0001 | 25X130 |
| MUP.401674 | 81 41306 0081 | 25X143 |
| MUP.401674 | 81 41306 0072 | 25X143 |
| MUP.401674 | 81 41306 0058 | 25X143 |
| MUP.401675 | 81 41306 0084 | 25X143 |
| MUP.401675 | 81 41306 0080 | 25X143 |
| MUP.401675 | 81 41306 0071 | 25X143 |
| MUP.401675 | 81 41306 0067 | 25X143 |
| MUP.401675 | 81 41306 0055 | 25X143 |
| MUP.401676 | 81 41306 0095 | 30X142 |
| MUP.401677 | 81 41306 0088 | 30X143 |
| MUP.401678 | 81 41306 0089 | 30X145 |
| MUP.401679 | 81 41306 0092 | 30X160 |
| MUP.401679 | 81 91001 0453 | 30X160 |
| MUP.401680 | 81 41306 0085 | 30X162 |
| MUP.401680 | 81 41306 0078 | 30X162 |
| MUP.401680 | 81 41306 0001 | 30X162 |
| MUP.401680 | 81 41306 0032 | 30X162 |
| MUP.401680 | 81 41306 0074 | 30X162 |
| MUP.401681 | 81 41306 0097 | 30X162 |
| MUP.401681 | 81 41306 0094 | 30X162 |
| MUP.401682 | 81 41306 0096 | 30X162,5 |
| MUP.401683 | 81 91020 0327 | 40X161 |
| MUP.401683 | 81 91020 0255 | 40X161 |



CALIPER REP KIT



| | |
|-------------|------------------------|
| MUCIT REF | MUP.402857 |
| OEM NO | 81 50822 6023 |
| ENGINE TYPE | TG-A (KNORR NO:000375) |

DIMENSIONS

PISTON RETAINING PLATE



| | |
|-------------|-------------------------|
| MUCIT REF | MUP.402853 |
| OEM NO | 81 50822 0006 |
| ENGINE TYPE | MERITOR NO:68321678PK10 |

DIMENSIONS

CALIPER COVER REP KIT



| | |
|-------------|-----------------------------|
| MUCIT REF | MUP.402858 |
| OEM NO | 81 50822 6025 |
| ENGINE TYPE | TG-A (KNORR NO:II397690063) |

DIMENSIONS

BRAKE DISC REP.KIT



| | |
|-------------|---------------|
| MUCIT REF | MUP.402378 |
| OEM NO | 81 50802 6016 |
| ENGINE TYPE | 19.423/463 |

CALIPER REP KIT



| | |
|-------------|--------------------------------|
| MUCIT REF | MUP.402854 |
| OEM NO | 81 50822 6019 81 50822 6034 |
| ENGINE TYPE | TG-A (KNORR NO:001532) |

CALIPER REP KIT



| | |
|-------------|----------------------------------|
| MUCIT REF | MUP.402855 |
| OEM NO | 81 50822 6031 81 50822 6020 |
| ENGINE TYPE | TG-A (KNORR NO:001300-010603) |

CALIPER REP KIT



| | |
|-------------|---|
| MUCIT REF | MUP.402856 |
| OEM NO | 81 50822 6022 81 50822 6032 81 50822 6007 |
| ENGINE TYPE | TG-A (KNORR NO:000944-010604) |

BRAKE DISC REP.KIT FULL



| | |
|-------------|---------------|
| MUCIT REF | MUP.402376 |
| OEM NO | 81 50822 6001 |
| ENGINE TYPE | 12.153/163 |

DIMENSIONS

STABILIZER BEARINGMUCIT REF **MUP.100340**

DIMENSIONS

OEM NO **6771515**

ENGINE TYPE

**BEARING**MUCIT REF **MUP.101269**

DIMENSIONS

OEM NO **1622838**ENGINE TYPE **FH 12-16****STABILIZER BEARING**MUCIT REF **MUP.101260**

DIMENSIONS

OEM NO **8152645**ENGINE TYPE **ALL****BALL JOINT REP. KIT**MUCIT REF **MUP.101253**

DIMENSIONS

OEM NO **273706**ENGINE TYPE **ALL****BALL JOINT REP. KIT**MUCIT REF **MUP.101255**

DIMENSIONS

OEM NO **273375**ENGINE TYPE **ALL****BALL JOINT REP. KIT**MUCIT REF **MUP.100384**

DIMENSIONS

OEM NO **271188**ENGINE TYPE **F 10/12/16-FL 7/10/12**

BALL JOINT REP. KIT



| | |
|-------------|--------------|
| MUCIT REF | MUP.100388 |
| OEM NO | 273374 |
| ENGINE TYPE | F 10-N 10/12 |

DIMENSIONS

BALL JOINT REP. KIT



| | |
|-------------|------------|
| MUCIT REF | MUP.102088 |
| OEM NO | 274069 |
| ENGINE TYPE | |

DIMENSIONS

BALL JOINT REP. KIT



| | |
|-------------|------------|
| MUCIT REF | MUP.102089 |
| OEM NO | 3090712 |
| ENGINE TYPE | |

DIMENSIONS

BALL JOINT REP. KIT



| | |
|-------------|------------|
| MUCIT REF | MUP.102090 |
| OEM NO | 3090015 |
| ENGINE TYPE | |

DIMENSIONS

BALL JOINT REP. KIT



| | |
|-------------|------------|
| MUCIT REF | MUP.102091 |
| OEM NO | 3133173 |
| ENGINE TYPE | |

DIMENSIONS

IMPELLER



| | |
|-------------|----------------------|
| MUCIT REF | MUP-BB-0012 |
| OEM NO | 1675638 - 3183676 |
| ENGINE TYPE | FH12 D12A (9 BLADES) |

DIMENSIONS

IMPELLER

MUCIT REF **MUP.102213**
 OEM NO **1676714**
 ENGINE TYPE **FH12 D12B (12 BLADES)**

DIMENSIONS

**IMPELLER**

MUCIT REF **MUP.101750/1**
 OEM NO
 ENGINE TYPE **FH12/D12C (12 BLADES)**

DIMENSIONS

**IMPELLER**

MUCIT REF **MUP.101750/2**
 OEM NO
 ENGINE TYPE **FH12/D12C (9 BLADES)**

DIMENSIONS

**IMPELLER**

MUCIT REF **MUP.102246**
 OEM NO **3183685 - 20587287**
 ENGINE TYPE **TD61-63-71-73(12 BLADES)**

DIMENSIONS

**IMPELLER**

MUCIT REF **MUP.102247**
 OEM NO **1675465**
 ENGINE TYPE **TD61-63-71-73(7 BLADES)**

DIMENSIONS



ROLLER



| | |
|-------------|------------|
| MUCIT REF | MUP.500513 |
| OEM NO | 1514087 |
| ENGINE TYPE | 124 |

DIMENSIONS

ROLLER



| | |
|-------------|------------|
| MUCIT REF | MUP.500512 |
| OEM NO | 1514086 |
| ENGINE TYPE | 124 |

DIMENSIONS

ROLLER



| | |
|-------------|------------|
| MUCIT REF | MUP.500665 |
| OEM NO | 1503113 |
| ENGINE TYPE | 124 |

DIMENSIONS

VALVE COVER GASKET UPPER



| | |
|-------------|------------|
| MUCIT REF | MUP.500585 |
| OEM NO | 1414422 |
| ENGINE TYPE | 124 |

DIMENSIONS

VALVE COVER GASKET UPPER



| | |
|-------------|-------------------|
| MUCIT REF | MUP-BB-0011 |
| OEM NO | 1411851 - 1401984 |
| ENGINE TYPE | 124 |

DIMENSIONS

VALVE COVER GASKET LOWER



| | |
|-------------|------------|
| MUCIT REF | MUP.500587 |
| OEM NO | 1470506 |
| ENGINE TYPE | 124 |

DIMENSIONS

STABILIZER BUSHING

| | |
|-------------|----------------------|
| MUCIT REF | MUP.200107 |
| OEM NO | 763523 |
| ENGINE TYPE | F1700-1900/F75-85-95 |

DIMENSIONS



BALL JOINT REP. KIT.

| | |
|-------------|---------------------------|
| MUCIT REF | MUP.200115 |
| OEM NO | 691704 |
| ENGINE TYPE | F75-85-95/ 1900-2300-2700 |

DIMENSIONS



BALL JOINT REP. KIT.

| | |
|-------------|------------|
| MUCIT REF | MUP.200116 |
| OEM NO | 69600 |
| ENGINE TYPE | |

DIMENSIONS



BALL JOINT REP. KIT.

| | |
|-------------|------------|
| MUCIT REF | MUP.200122 |
| OEM NO | 1271124 |
| ENGINE TYPE | |

DIMENSIONS



BALL JOINT REP. KIT.

| | |
|-------------|------------|
| MUCIT REF | MUP.200123 |
| OEM NO | 693778 |
| ENGINE TYPE | F95-CF95 |

DIMENSIONS



BALL JOINT REP. KIT.

| | |
|-------------|---------------------|
| MUCIT REF | MUP.200463 |
| OEM NO | 1398368 |
| ENGINE TYPE | 65XF-75XF-85XF-95XF |

DIMENSIONS



BALL JOINT REP. KIT.



| | |
|-------------|------------|
| MUCIT REF | MUP.200464 |
| OEM NO | 1376730 |
| ENGINE TYPE | |

DIMENSIONS

BALL JOINT REP. KIT.



| | |
|-------------|------------|
| MUCIT REF | MUP.200465 |
| OEM NO | 696320 |
| ENGINE TYPE | |

DIMENSIONS

TRAILER

MUDGUARD



| | |
|-------------|------------|
| MUCIT REF | MUP-T-0001 |
| OEM NO | UNIVERSAL |
| ENGINE TYPE | |

DIMENSIONS

CLAMP FOR MUDGUARD



| | |
|-------------|------------|
| MUCIT REF | MUP-T-0002 |
| OEM NO | UNIVERSAL |
| ENGINE TYPE | |

DIMENSIONS

OIL RESERVOIR

MUCIT REF MUP.301498
 OEM NO MB - 000 466 4502
 M.A.N. - 81 47301 6030
 VOLVO -
 SCANIA -
 DAF -
 IVECO -



OIL RESERVOIR - TRANSPAREN

MUCIT REF MUP.301494
 OEM NO MB - 000 466 4502
 M.A.N. - 81 47301 6047
 VOLVO -
 SCANIA -
 DAF -
 IVECO -



OIL RESERVOIR

MUCIT REF MUP-H-0001
 TYPE ALL TRACTORS



CAP

MUCIT REF MUP.301500
 OEM NO _____



OIL DIPSTICK

MUCIT REF MUP.301499
 OEM NO _____





TRACTORS

www.mucit.com

FAN SHOURED BIG TYPE

MUCIT REF MUP-T-0003

TYPE ALL



FAN SHOURED SMALL TYPE

MUCIT REF MUP-T-0004

TYPE ALL



AIR FILTER BIG TYPE

MUCIT REF MUP-T-0005

 TYPE TŪMOSAN
 ERKUNT
 NEW HOLLAND
 FARMTRAK
 ARMTRAK


AIR FILTER SMALL TYPE

MUCIT REF MUP-T-0006

 TYPE TŪMOSAN
 ERKUNT
 NEW HOLLAND
 FARMTRAK
 ARMTRAK


CLAMP FOR AIR FILTER BIG TYPE

MUCIT REF MUP-T-0007

 TYPE TŪMOSAN
 ERKUNT
 NEW HOLLAND
 FARMTRAK
 ARMTRAK


CLAMP FOR AIR FILTER SMALL TYPE

MUCIT REF MUP-T-0008

 TYPE TŪMOSAN
 ERKUNT
 NEW HOLLAND
 FARMTRAK
 ARMTRAK


DUST PAN BIG TYPE



MUCIT REF MUP-T-0009
TYPE OLD MODELS

DUST PAN MIDDLE TYPE



MUCIT REF MUP-T-0010
TYPE OLD MODELS

DUST PAN SMALL TYPE



MUCIT REF MUP-T-0011
TYPE OLD MODELS

DUST GLASS BIG TYPE



MUCIT REF MUP-T-0012
TYPE OLD MODELS

DUST GLASS MIDDLE TYPE



MUCIT REF MUP-T-0013
TYPE OLD MODELS

DUST GLASS SMALL



MUCIT REF MUP-T-0014
TYPE OLD MODELS

FAN FOR DUST PAN BIG TYPE
MUCIT REF MUP-T-0015

TYPE OLD MODELS

FAN FOR DUST PAN MIDDLE TYPE
MUCIT REF MUP-T-0016

TYPE OLD MODELS

FAN FOR DUST PAN SMALL TYPE
MUCIT REF MUP-T-0017

TYPE OLD MODELS

MUDGUARD WIDENER , L BIG TYPE
MUCIT REF MUP-T-0018

TYPE ALL

MUDGUARD WIDENER , R BIG TYPE
MUCIT REF MUP-T-0019

TYPE ALL

MUDGUARD WIDENER , L SMALL TYPE
MUCIT REF MUP-T-0020

TYPE ALL


MUDGUARD WIDENER , R SMALL TYPE



MUCIT REF MUP-T-0021
TYPE ALL

MUDGUARD



MUCIT REF MUP-T-0022
TYPE TÜMOSAN
ERKUNT
NEW HOLLAND
FARMTRAK
ARMTRAK

DIMENSIONS 135 X 960 mm - Single Taking

MUDGUARD



MUCIT REF MUP-T-0023
TYPE TÜMOSAN
ERKUNT
NEW HOLLAND
FARMTRAK
ARMTRAK

DIMENSIONS 275 X 980 mm - DT

MUDGUARD



MUCIT REF MUP-T-0024
TYPE TÜMOSAN
ERKUNT
NEW HOLLAND
FARMTRAK
ARMTRAK

DIMENSIONS 310 X 1200 mm - DT

MUDGUARD



MUCIT REF MUP-T-0025
TYPE TÜMOSAN
ERKUNT
NEW HOLLAND
FARMTRAK
ARMTRAK

DIMENSIONS 400 X 1250 mm - DT

MUDGUARD WITH BRACKET



MUCIT REF MUP-T-0038
TYPE TÜMOSAN
ERKUNT
NEW HOLLAND
FARMTRAK
ARMTRAK

DIMENSIONS 135 X 960 mm - Single Taking

MUDGUARD WITH BRACKET

MUCIT REF MUP-T-0026

DIMENSIONS 275 X 980 mm - DT

 TYPE
 TÜMOSAN
 ERKUNT
 NEW HOLLAND
 FARMTRAK
 ARMTRAK


FAN FOR DUST PAN BIG TYPE

MUCIT REF MUP-T-0027

DIMENSIONS 275 X 980 mm - DT

 TYPE
 TÜMOSAN
 ERKUNT
 NEW HOLLAND
 FARMTRAK
 ARMTRAK


FAN FOR DUST PAN BIG TYPE

MUCIT REF MUP-T-0028

DIMENSIONS 275 X 980 mm - DT

 TYPE
 TÜMOSAN
 ERKUNT
 NEW HOLLAND
 FARMTRAK
 ARMTRAK


FAN FOR DUST PAN BIG TYPE

MUCIT REF MUP-T-0029

DIMENSIONS 275 X 980 mm - DT

 TYPE
 TÜMOSAN
 ERKUNT
 NEW HOLLAND
 FARMTRAK
 ARMTRAK


FAN FOR DUST PAN BIG TYPE

MUCIT REF MUP-T-0030

DIMENSIONS 310 X 1200 mm - DT

 TYPE
 TÜMOSAN
 ERKUNT
 NEW HOLLAND
 FARMTRAK
 ARMTRAK


FAN FOR DUST PAN BIG TYPE

MUCIT REF MUP-T-0031

DIMENSIONS 310 X 1200 mm - DT

 TYPE
 TÜMOSAN
 ERKUNT
 NEW HOLLAND
 FARMTRAK
 ARMTRAK


DUST PAN BIG TYPE



MUCIT REF MUP-T-0032
TYPE TÜMOSAN
ERKUNT
NEW HOLLAND
FARMTRAK
ARMTRAK

DIMENSIONS 310 X 1200 mm - DT

DUST PAN BIG TYPE



MUCIT REF MUP-T-0033
TYPE TÜMOSAN
ERKUNT
NEW HOLLAND
FARMTRAK
ARMTRAK

DIMENSIONS 310 X 1200 mm - DT

DUST PAN BIG TYPE



MUCIT REF MUP-T-0034
TYPE TÜMOSAN
ERKUNT
NEW HOLLAND
FARMTRAK
ARMTRAK

DIMENSIONS 400 X 1250 mm - DT

DUST PAN BIG TYPE



MUCIT REF MUP-T-0035
TYPE TÜMOSAN
ERKUNT
NEW HOLLAND
FARMTRAK
ARMTRAK

DIMENSIONS 400 X 1250 mm - DT

DUST PAN BIG TYPE



MUCIT REF MUP-T-0036
TYPE TÜMOSAN
ERKUNT
NEW HOLLAND
FARMTRAK
ARMTRAK

DIMENSIONS 400 X 1250 mm - DT

DUST PAN BIG TYPE



MUCIT REF MUP-T-0037
TYPE TÜMOSAN
ERKUNT
NEW HOLLAND
FARMTRAK
ARMTRAK

DIMENSIONS 400 X 1250 mm - DT